



How to turn on the Vocal Harmony function on the KD160 and 165


Press the GLOBAL button





Go to PAGE 14



The display shows



Press the DRUM-PERC/DRUM button until **Input1/2: 1/2 Int.FX** changes to **Input 1/2: 1/2 Vocal/Guitar**



Now you are ready to use the Vocal Harmony effect