

Appendix C

Standard K2600 ROM Objects

In This Appendix

- ProgramsC-4
- SetupsC-5
- QA BanksC-6
- SongsC-6
- StudiosC-7
- KeymapsC-9
- SamplesC-10
- FX Presets.....C-11
- FX Algorithms.....C-13
- Program Control Assignments.....C-14

The objects listed in this Appendix are current with operating system version 1.01. Your K2600 probably has version 1.01 objects installed. Here's how you can check the version of the objects you have installed:

1. Press the **Master** mode button to enter Master mode.
2. Select the Intonation parameter.
3. Change its value to **18**. You should see something like this: **18 Obj B1.00**. This "intonation table" is actually the version number of the K2600's basic object file (hence the **B**). If you scroll higher in the list, you may see other version numbers, depending on the ROM block options you have.

If your instrument doesn't have version 1.01 objects, you can get them from our website:

<http://www.youngchang.com/kurzweil/html/downloads.html>

K2600 Program List

The preset programs in the K2600 are organized by instrument category. You'll find a few representatives of each instrument sampled for the base ROM sound block, as well as synthesized instrument emulations, commonly used synthesizer timbres, and templates for new programming. We hope you find it a good starting point for your own work.

Setup List

The setup is a combination of up to eight zones, each with independent MIDI channel and control assignments. Setups can be played on rack models via the Local Keyboard Channel feature: in MIDI mode on the RECEIVE page, change the value of the LocalKbdCh parameter from **None** to a channel of your choice, and set your MIDI source to send on only that channel. Now, any note that comes in on that channel will be remapped according to the display channel (in Program mode) and according to the setup (in Setup mode).

Conventional Controller Assignments

There are 99 factory setups in the K2600. You'll find unique internal program combinations, arpeggiator examples, special ribbon and controller functions, and templates for user-defined setups. With as many as 24 assignable controllers shared among 8 independent zones, K2600 setups can be quite powerful, and they require some experimentation to find all their features and nuances. In order to make this process easier, many setups are programmed according to certain conventions. The sliders generally provide mixing capabilities either as group faders or individual zone faders. They also provide control over timbre, effects mix, and clock tempo. Other conventions include those listed in Table -C-1 (these are the default settings for Setup 97 **ControlSetup**).

Slider A: Data	Continuous Controller Pedal 1: Foot (MIDI 4)
Slider B: MIDI 22	Continuous Controller Pedal 2: Breath (MIDI 2)
Slider C: MIDI 23	Small Ribbon Position: Aux Bend 2
Slider D: MIDI 24	Small Ribbon Pressure: Mono Pressure
Slider E: MIDI 25	Large Ribbon: Aux Bend 1
Slider F: MIDI 26	Pitch Wheel: BendUp
Slider G: MIDI 27	Mod Wheel: MWhl
Slider H: MIDI 28	Panel Switch 1: Arpeggiator On/Off
Footswitch 1: Sustain	Panel Switch 2: MIDI 29
Footswitch 2: Sostenuto	Mono Pressure: MPress
Footswitch 3: Soft Pedal	
Footswitch 4: TapTempo	

Table C-1 Default Physical Controller Assignments

MIDI notes can be triggered from many controllers including pedals, switches, sliders and the ribbons.

Special Purpose Setups

There are three special setups at the end of the Zeros bank:

- 97 Control Setup** Lets you define controller assignments in Program mode. You can customize and select the control setup on the MIDI-mode TRANSMIT page.
- 98 Clear Setup** A template for creating your own control assignments from a clear palette.
- 99 Default Setup** Lets you create your own setups from our common settings. The NewZn parameter uses this setup as its template for creating new zones.

Standard K2600 ROM Objects

Programs

Programs

1	Concert Piano 1	61	Industry Set II	121	NUChoir^SpaceVox	181	Synth Bell 1^2
2	Stereo Solo Pno	62	General MIDI Kit	122	Marimbae^Vibeish	182	DynPercMix^Gator
3	Brt Concert Pno	63	Slam'nDrumsII GM	123	EchoBars SliderE	183	Workingman Space
4	Rok Piano	64	ElectroDrumsetGM	124	Malleflute Split	184	OronicoKno^Shift
5	Piano for Layers	65	SmallKit+Perc MW	125	Malletoo	185	Ethereal Dawning
6	DrkPno^ArakisPno	66	Steel Str Guitar	126	Highlandistic	186	RAVReligion^Prey
7	Honky-Tonk	67	12-Str Guitar	127	Buzz Kill	187	Voyage
8	Pno&Syn/AcString	68	Spark Guitar	128	Harshey's	188	WispSingers^Glass
9	ClassicPiano&Vox	69	Blue Moods	129	Spunter	189	Luscious
10	E Grand Stack	70	SloChrsGtr^Harms	130	Crumper	190	LightMist^Padify
11	Piano D'Biggy	71	ES335^Abercrmbie	131	Zeek	191	VortexRev^Launch
12	DynEPiano^EPnoPF	72	SliderDistJazzGt	132	Elephantiasis	192	Hello^A No Way
13	FM-ish E-Piano	73	Crunchy Lead	133	SoftMatrix12 5th	193	Environments
14	Suitcase E Piano	74	NooMutes^WahTaur	134	TchRezoid^Hungry	194	Gremlin Groupies
15	PhunkEPno^FonkMW	75	CeeTaur^Kotolin	135	MatchStik^NuDigi	195	Lost In Space
16	Clavinators 1^2	76	Liquid T Lead	136	Peppers Digiclub	196	Lunar Wind
17	Spaceychord 1^2	77	Square Lead	137	Frog^LowNoteTalk	197	Noise Toys
18	D'Nu Clavs 1^2^3	78	AlaZawi Take 2	138	Oink Doink	198	Click
19	VAST B3! PW+CC2	79	Modulead	139	Wheepy Dood	199	Default Program
20	Rock Organ	80	Polyreal Mini	140	Funk-O-Matic	750	Testify
21	Ballad Organ	81	ModularLead1^2^3	141	Pulsemonster5ths	751	Prog Rock Organ
22	Gospel Organ	82	Soul Boy Lead	142	OB Pad^OB Brass	752	Syn Rock Organ
23	Overdrive Organ	83	Flutey Leads	143	Detooner^BigPMW	753	Dirty Syn B
24	Perc Organ	84	Hrmnica^Accrdion	144	TeknoBallCrusher	754	CleanFullDrawbar
25	Chiffy Pipes	85	Trumpets^BrBrass	145	VTrig SquareHead	755	Loungin'
26	Offertory	86	Hip Brass	146	Razor Saw	756	Mild Grunge
27	Pedal Pipes	87	Brass De ROM	147	Razorip Buzzsaw	757	WarmDriveBallad
28	Church Organ	88	BigBand^Hornz	148	Pulse Pass	758	Gospel Drawbars
29	DualBass^SlapBas	89	Z-Plane Brass	149	Nordic Square	759	Live Drawbars
30	Warm Bass 1^2	90	OrcBrs^FrnchBone	150	Rezonant Snob	760	Keith's Revenge
31	SustBass^MixBass	91	Brt Saxy Section	151	Borfin'Jumps^RPT	761	SynthPerc Rocker
32	RickenBass	92	Brt Saxy/Split	152	Elektro Funk	762	LORD'S Blown Amp
33	Synth Fretless	93	Mr. Parker	153	Acid	763	Dist GigantorGan
34	Moogy Bass 1^2	94	Dynasax	154	Rancid	764	SynOrganHologram
35	Moogy Bass 3^4	95	DynTrumpet^Miles	155	Fuse	765	SynChurch Organ
36	MatrixBigBass1^2	96	Wawa Trumpet MW	156	Squwee Monosync	766	SynChrch&Chorale
37	PittBass mono1^2	97	Almost Muted MW	157	Generic Ravelead	767	Choir & Pipes
38	Punch Bass 1^2	98	Solo Trombone	158	Notch Sink	768	Theater Flutes
39	Tee Bee This MW	99	Jazz Band	159	Grungesync Sweep	769	Even Tuned Bars
40	BottomFeed^Pulse	100	W.C.Flute^Winds	160	Rezzysaws	770	Concert Piano 2
41	SkoolBass^Simple	101	Baroque Flute	161	Prophet Sync	771	Studio Grand
42	MonoBass^FixBass	102	Synth Calliopies	162	Glider	772	Soft Piano
43	Ravelike Basses	103	Incan	163	Alaska Glide MW	773	MonoStudioGrand
44	Junosis^Geo-Bass	104	String Orchestra	164	Rave Classic	774	RandomPan Grand
45	AceBass^ChirpBas	105	ClassicalStrings	165	Meditator^SloEns	775	Funky Piano
46	Gritz	106	StSloStr^SilkStr	166	Tranquil Picked	776	Piano Chase
47	Homey Saw	107	BigStrgs^FIngStr	167	The Chaser	777	Grand & Elec 1
48	OG	108	Chamber Ensemble	168	Enterprize^MTree	778	Grand & Elec 2
49	Lowdown Bass	109	PsuedoViolin 1^2	169	Orgazmica	779	Detuned Piano
50	SquashStudio Kit	110	Slow Solo Cello	170	Universal	780	Ballad Piano
51	Retro Skins MW	111	Horn&Flute w/Str	171	Asian Digital	781	Piano&SpaceyPad
52	2 Live Kits 2 MW	112	DynOrch^WTellOrc	172	Wheel Wave Sweep	782	Lush Piano Pad
53	Garage Kit II MW	113	Touchy Orchestra	173	Arystal^InTheAir	783	Rotating Piano
54	Jazz Kit II	114	Synth Strings	174	Cymbal Singers	784	MajesticPianoism
55	Hoppy Kit!	115	MelloStr^ShineOn	175	BriteBells^Glock	785	Sonar Piano
56	L'il Nipper Kit	116	Mellotron MW	176	Crystalline^RX7	786	Pop Grand
57	Geo-Kit MW+22	117	RavStrngs^Solina	177	Wave Power X 2	787	Grandsichord
58	Lo-Fi Vinyl Kit	118	Choir Strings	178	Trinibell		
59	Technoo Kit	119	CathdrVox^8veVox	179	Frozen^Pizzibell		
60	VAST Sliders 808	120	Mixed Choir	180	Den City		

Setups

1	Tonal Raver	51	F1 Latino Groove
2	Kickin' Wave	52	Dream Pad RbnVel
3	Hunkster Funk	53	C2 Jam
4	Off Your Rocker	54	Nu C2 & Lead
5	Shimmer Hop	55	Percolator
6	Slow Hipmeister	56	Acid Prog C2
7	Slow Driver	57	Krazed Keith
8	Acidic Dance	58	Conn Trolled
9	JR's Dance	59	Ravin & Droolin
10	Drum & Wave	60	Clanger
11	Jetzen's Trance	61	Waverado Rbn SW
12	Euro-Rave	62	Elephantitus
13	Acoustic Country	63	Ether Dreams
14	Trip-Hopper	64	Rbn Slider Bells
15	Latinease	65	Munchkin Factory
16	Hop II	66	Clink Split
17	Slider Grooves	67	Lush World
18	Wah Blues	68	IX Dancers
19	DrumsE-B1Fills#3	69	MidEasternBells
20	Controlled FX	70	FM Morpher
21	Quantum Mechanix	71	Slo n' Funky
22	Driven	72	Liquid Guitars
23	Drewz Groove	73	Big & Meaty
24	Jazz Session 101	74	Glazing
25	Piano Trio & Str	75	Play With Balls
26	Jazzy's Band	76	Pepper Digital
27	SmoothEPiano	77	De Tant
28	Orchescape	78	Old & New Pad
29	New Rock Band	79	Punch-n-Oinky
30	Harpsichord&Vox	80	Brazzine
31	Analogued	81	Pad W/ Rotor
32	Elegant Grandeur	82	Tang Nebulae
33	Cathedral	83	Boink Head
34	Church Organ	84	Voyager
35	Jazz & Pop Brass	85	Changling
36	Glory Orchestra	86	Wash Cycle
37	Super Lush	87	NewTaleSpinnin'
38	Scoring Stage	88	Electric Swirl
39	Happnin' Brass	89	Land Of Giants
40	RbnSpltB3+MIDIpd	90	Desert Planet
41	SpltVASTB+MIDIpd	91	Terraformation
42	Guitars Sent Her	92	Sparkle & Bass
43	GB 6Keys&2Basses	93	Area 51 1/2
44	Comper Keys	94	Slider Player
45	Bold Beauty	95	Synthozilla
46	Nubian Nightfall	96	Dr.Distorted
47	Polar Reverie	97	ControlSetup
48	Vapor Drawing	98	Clear Setup
49	Siamese Ribbon	99	Default Setup
50	Spacegroove		

QA Banks

1	Keys
2	Analog
3	Hard Edge
4	Jazz
5	Rock/Blues
6	Classical
7	Film Score
8	Jukebox
9	Basic QA Bank

Songs

2	Slow Drive Arr
3	Slow Drive Sng
4	"2WaveSeqCh5,6Arr"
5	"2WaveSeqCh5,6Sng"
6	HybridGroove Arr
7	Wave Seq Ch6 Arr
8	Wave Seq Ch6 Sng
9	Funk Groove1 Arr
10	Funk Groove1 Sng
11	Funk Groove2 Arr
12	Funk Groove2 Sng
13	Funk Groove3 Sng
14	DiscoGroove1 Sng
15	DiscoGroove2 Sng
16	Funk Fill 1 Sng
17	Funk Fill 2 Sng
18	Hybrid Funk Arr
19	Hybrid Funk Sng
20	Slow Hip-Hop Arr
21	Slow Hip-Hop Sng
22	Acid Rock Arr
23	AcidRock Sng ptA
24	AcidRock Sng ptB
25	AcidRock Sng ptC
26	AcidRockSngDrums
27	Rock Groove Arr
28	Rock Groove Sng
29	UpBluesGrooveArr
30	UpBluesGrooveSng
31	AcoustiGrooveArr
32	AcoustiGrooveSng
33	Rave Groove Arr
34	Rave Groove Sng
35	Hip Groove Arr
36	Hip Groove Sng
37	Mod Groove 1 Arr
38	Mod Groove 1 Sng
39	ElectroGrooveArr
40	ElectroGrooveSng
41	Dance Groove Arr
42	Dance Groove Sng
43	WayOutGroove Arr
44	WayOutGroove Sng
45	Tek Latin Arr
46	Tek Latin Sng
47	Sound FX Arr
48	Sound FX Sng
49	Jazzmen Arr
50	Jazzmen Sng

Studios

1	RoomChorDelay Hall	61	CompEQmphCh Room	121	AuxMPFgLasr Plt
2	RmChorChRv Hall	62	BthQFlg4Tap Hall	122	AuxShap4MD Plate
3	RoomChorCDR Hall	63	ChmbTremCDR Room	123	FlgEnv4Tap Plate
4	RoomChor Hall	64	ChmbCmpFIRv Hall	124	EnhrFlgCDR Plate
5	RoomChrCh4T Hall	65	ChamDstEcho Room	125	AuxRingPFD Plate
6	RoomFingCDR Hall	66	ChamFlg4Tap Hall	126	GtRvShapMDI Room
7	RoomFlgEcho Hall	67	ChmbEnv4Tap GtRv	127	GtdEnhcStlm Room
8	RmFingStlmg Garg	68	CmbrShapLsr Hall	128	Gtd2ChrEcho 2Vrb
9	RmFlgChDelay Room	69	AuxPtchDst+ Chmb	129	GtdEnhcStlm Hall
10	ChmbFlgGtRv Hall	70	AuxChorFIRv Cmbr	130	AuxEnvSp4T GtVrb
11	RoomFingCDR Hall	71	AuxChorFIRv Cmb2	131	GtRbSwpFlt Lasr
12	RoomFingLsr Echo	72	AuxChorFIRv Cmb3	132	GtRbSwpFlt FIDelay
13	RmFlgFXFing Flng	73	AuxChorFIRv Cmb4	133	ChRvStlEcho Hall
14	SpaceFing Hall	74	HallFlgChDI Room	134	ChorChorCDR Spac
15	ChmbFingCDR Verb	75	HallPtchLsr Hall	135	ChDIstEQ Hall
16	RoomPhsrCDR Hall	76	HallGateFl4T Bth	136	AuxDPanCDR ChPlt
17	RmPhsrQuFlg Hall	77	HallChorFDR Room	137	AuxChorFing CDR
18	RoomPhsr Space	78	HallPtchPtFl Lsr	138	AuxEnhcSp4T CDR
19	RmEQmphEcho Comp	79	HallFing8Tp Room	139	AuxPtchDst+ ChRv
20	RmEQmphEcho Hall	80	HallChrEcho Room	140	EnhcChorChDI PCD
21	RmEQmph4Tp Room	81	HallChorCDR Hall	141	AuxPoly FDR
22	RmEQmph4Tap Hall	82	HallRsFltChDI Rm	142	EnhcChorChDI FDR
23	RmSweepEcho Hall	83	Hall ChDelay Hall	143	EnhcChrChDI FDR2
24	RoomResEcho Hall	84	HallFlgChDI Hall	144	AuxRotoSp4T FIRv
25	RmRotoFl4T CmpRv	85	Hall Room SRS	145	AuxRotaryFDR Plt
26	RoomSRSCDR Hall	86	Hall Room Room	146	RotoOrgFX Hall
27	RoomSRSRoom Room	87	Hall CmpRvb	147	CmpRvbFIDI Hall
28	RoomSRSchDI Hall	88	HallFing Hall	148	AuxEnhSp4T RvCm
29	RoomSRSCDR CDR	89	HallRoomChr Hall	149	AuxPtchRoom RvCm
30	RmStlmgChDI Hall	90	AuxPhsrFDR Hall	150	PhsrChorCDR Phsr
31	RoomSRSRoom Chmb	91	AuxChrDist+ Hall	151	ChDISp4TFIDI Phs
32	RoomSRSRoom Hall	92	AuxFlgDist+ Hall	152	AuxFlgDst+ ChLsD
33	ChmbCompCDR Hall	93	AuxChrDist+ Hall	153	AuxFlgDst+ ChLs2
34	RoomCmpChor Hall	94	AuxChorMDelay Hall	154	RoomRoomSRS CmRv
35	RoomComp Hall	95	AuxChorSp6T Hall	155	RoomRoom Room
36	RoomComp Hall	96	AuxChorChDI Hall	156	GtRvPlate Hall
37	BthComp SRS Hall	97	AuxPhasStlm Hall	157	RoomRoom SRS
38	RoomCmpCh4T Hall	98	AuxFingCDR Hall	158	EnhcSp4T Hall
39	RmDsRotFl4t RvCm	99	AuxPhsFIDl Hall	159	Room RoomChr SRS
40	RoomRmHall Hall	100	AuxSRSRoom Hall	160	KB3 V/C ->Rotary
41	Room Room SRS2	101	AuxFingLasr Hall	161	EQStlmg 5BndEQ
42	RoomRmHall Hall	102	AuxEnh4Tap Hall	162	Aux5BeqStlm Hall
43	Room Room Hall	103	EnhcChorCDR Hall	163	10Band Stlm Hall
44	Room Hall Hall	104	EnhChorChDI Hall	164	3BndCmp PtFl
45	Room Room Hall2	105	EnhcChor Plate	165	AuxDst+Lsr Plt
46	Room Room Hall3	106	CompFlgChor Hall	166	AuxRsFltEnvSwFlt
47	Room Room Hall4	107	ChorChorFlg Hall	167	AuxChorEnvF Hall
48	Room Hall Hall2	108	ChapelSRS Hall	168	AuxChRvEncr Chor
49	Sndbrd Room Hall	109	ChapelSRS Hall2	169	AuxChrDstEQ Room
50	Sndbrd Rm Hall2	110	Chapel Room Hall	170	Aux ChDISRS Hall
51	Room Room Hall3	111	PltEnvFl4T Room	171	Aux EQFing DstEQ
52	AuxChrMDelay Room	112	PlatEnvFl4T Flt	172	AuxFingPhsr Lasr
53	AuxFingChRv Room	113	PltEnvFl4T Plate	173	AuxFIShQFlg Hall
54	AuxShp4MDelay Hall	114	PltTEnvFlg Plate	174	AuxFlgDist+ Room
55	AuxDistLasr Room	115	PlateRngMd Hall	175	Aux GtVbFl4T Bth
56	AuxEnhSp4T Class	116	AuxDist+Echo Plt	176	AuxRvRvQFlg Hall
57	AuxDistLasr Acid	117	AuxEnvSp4T Plate	177	AuxRvRbShapeChmb
58	EnhcManPhs Room	118	AuxShap4MD Plate	178	AuxSpinMDelay Room
59	EnhcFlg8Tap Room	119	AuxChorDist+ Plt	179	Aux SweepEchoBth
60	EnhcCmpFing Room	120	AuxShFlgChDI Plt	180	AuxRoto&DsFDRPlt

Standard K2600 ROM Objects

Studios

181	AuxRot&Ds2FDRPlt	831	Stereo Flanger
182	AuxFlgChDI Hall	832	Stereo Delay
183	AuxDstLsr CDR	833	4-Tap Delay
184	CPDIEnFltCmpGtRv	834	Chorus Delay
185	RotoOrgFX2 Hall	835	Flange Delay
186	ChDIFIPtLzVb Plt	836	Chorus 4-Tap
187	CDFIDelayPhRm Hall	837	Flange 4 Tap
188	CDR FlgRvb Hall	838	Chorus Echo
189	DstPhsPnLzVb CDR	839	Chorus Echoverb
190	DistRoom GrphEQ	840	Fast Flange
191	Enh Ch 4T Hall	841	Wash
192	FiltCmpExpFI CDR	842	Into The Abyss
193	LzVbFIDstEQ Room	843	Space Flanger
194	PhseDist Room	844	Flange Room
195	ChDelayRvFIRv Hall	845	Predelay Hall
196	RmRotr&DstChrPlt	846	Flange Echo
197	Clear Studio	847	Rotary Club
198	Pre-KDFX Studio	848	Rotary Hall
199	Default Studio	849	Chorus
800	Sweet Hall	850	Soundbrd/rvb
801	Small Hall	851	Percussive Room
802	Medium Hall	852	Brt Empty Room
803	Large Hall	853	Mosque Room
804	Big Gym	854	New Gated
805	Bright Plate 1	855	Chorus Slap Room
806	Opera House	856	Chorus Bass Room
807	Live Chamber	857	New Chorus Hall
808	Bathroom	858	Spacious
809	Med Large Room	859	Wash Lead
810	Real Room	860	New Hall Wet/Dryelay
811	Drum Room	861	Rich Delay
812	Small Dark Room	862	Glass Delay
813	Small Closet	863	Real Plate
814	Add Ambience	864	Real Niceverb
815	Gated Reverb	865	ClassicalChamber
816	Reverse Reverb	866	Empty Stage
817	Non-Linear	867	Long & Narrow
818	Slapverb	868	Far Bloom
819	Full Bass	869	Floyd Hall
820	Room + Delay	870	With A Mic
821	Delay Big Hall		
822	Chorus Room		
823	Chorus Smallhall		
824	Chorus Med Hall		
825	Chorus Big Hall		
826	Chor-Delay Room		
827	Chor-Delay Hall		
828	Flange-Delay Room		
829	Flange-Delay Hall		
830	Stereo Chorus		

Keymaps

1	Grand Piano	62	10in Dry Tom	121	Drawbars 1-4, 8	181	Shift Guitar
2	Dual Elec Piano	63	12in Dry Tom	122	Organ Wave 1	182	Syn Guitar
3	Hard Elec Piano	64	15in Dry Tom	123	Organ Wave 2	183	Syn Voices
4	Soft Elec Piano	65	13in Amb Tom	124	Organ Wave 3	184	Syn Voices 2
5	Voices	66	15in Amb Tom	125	Organ Wave 4	185	Perc Voice
6	Ensemble Strings	67	16in Amb Tom	126	Organ Wave 5	186	Synstrings 1
7	Elec Jazz Guitar	68	Reversals	127	Organ Wave 6	187	Synstrings 2
8	Acoustic Guitar	69	Reverse Bell	128	Organ Wave 7	188	Syn Piano
9	5 String Guitar	71	Bidir Amb Kick 1	129	Partials 1-3	189	Funny Perc
10	Dual E Bass	72	Reverse Snare	130	Partials 4-7	190	TechnoLoops
11	Elec Pick Bass	73	Conga Bass	131	Partials 8-12	191	Hat Loop
12	Elec Slap Bass	74	Conga Slap	132	Partials 13-20	199	Silence
13	Finger Atk Bass	75	Conga Tone	133	Partials 21-30	770	Stereo Piano
14	Flute	76	Syn Conga Tap	134	Partials 1&2	771	Piano Left
15	Tenor Saxophone	77	Timbale	135	Partials 3&4	772	Piano Right
16	Sax no Altissimo	78	Timbale Shell	136	Partials 5-7	773	Pno440 Left
17	Trumpet	79	Cabasa	137	Partials 8-10	774	Pno440 Right
18	Trombone	80	Clave	138	Partials 11-15	775	Mono Piano
19	Trombone/Trumpet	81	Cowbell	139	Partials 16-21	776	Mono Piano 440
20	Bone/Trp 2	82	Tambourine	140	Partials 2-4	777	Hybrid Piano 1
21	Trombet	83	Handclaps	141	"Partials5,7,9,11"	778	Way Dull Piano
22	Trumpbone	84	Reverse Crash	142	"Partials 1,2,4"		
23	Preview Drums	85	Reverse Clsd Hat	143	"Partials 1,2,4,6"		
24	Dry Kit 1	86	Reverse Open Hat	144	Partials 3-5		
25	Dry Kit 2	87	Reverse hat loop	145	Partials 1&3		
26	Amb Kit 1	88	Chiff	146	"Partials 1,3,5"		
27	Amb Kit 2	89	Chirp	147	Partials 1&4		
28	Amb Kit 3	90	FM Bell Trans	148	Partials 1&6		
29	2 8ve Dry Kit	91	Waterphone	149	Partials 1&8		
30	General MIDI Kit	92	Metal Clank	150	Partials 1&12		
31	2-vel [1__2__]	93	TimbaleShell Atk	151	Sawtooth		
32	3-vel [1__2__3__]	94	Cowbell Atk	152	Dull Sawtooth		
33	4-vel [12__3__4__]	95	Timbale Atk	153	Very Dull Saw		
34	4-vel [1__2__3__4__]	96	Bell Attack	154	Square Wave		
35	5-vel [1__2__3__45]	97	Clave Atk	155	Dull Square		
36	6-vel [1__2__3456]	98	Wood Bar Atk	156	Very Dull Square		
37	7-vel [1__234567]	99	Conga Tone Atk	157	Buzzy Square		
38	8-vel [12345678]	100	Conga Slap Atk	158	Buzz Wave		
39	Ride Rim Cymbal	101	Elec Pno Atk	159	Hi Formant Wave		
40	Ride Bell Cymbal	102	Brass Attack	160	PrimeNumber Wave		
41	Crash Cymbal	103	Bow Attack	161	Triangle Wave		
42	Closed Hihat	104	Jazz Guitar Atk	162	Third Wave		
43	Slr Open Hihat	105	Steel Guitar Atk	163	Sine Wave		
44	Open Hihat	106	Perc Atk 1	164	ExtDynPrtls1		
45	Open>Close Hihat	107	Perc Atk 2	165	ExtDynPrtls2		
46	Foot Close Hihat	108	Perc Atk 3	166	ExtDynSaw		
47	Dry Kick 1	109	Wood Bars	167	Mellow Vox		
48	Dry Kick 2	110	Solo Strings	168	Silence		
49	Amb Kick 1	111	Six String Mutes	169	Synflute Brt		
50	Amb Kick 2	112	Oboe Wave	170	Synflute mello		
51	Amb Kick 3	113	Clav Wave	171	SlapBass/Guitar		
52	DrySnare1 soft	114	Elec Piano Wave	172	Mello Vox 2		
53	DrySnare1 Hard	115	Bell Wave	173	Shift Guitar 2		
54	Dual Dry Snare 1	116	Ping Wave	174	Single Mute		
55	Dry Snare 2	117	Drawbars 1-3	175	synElecJazzGtr		
56	Dry Snare 3	118	Drawbars 1-4	176	Sine Wave Click		
57	Amb Snare 1	119	Drawbars1-3 Dist	177	Fingered Bass 2		
58	Amb Snare 2	120	Full Drawbars	178	Ext Dual Bass		
59	Amb Snare 3			179	Syn Bass Pick		
60	Cross Stick			180	Syn Bass Slap		

Standard K2600 ROM Objects

Samples

Samples

1	Grand Piano	91	Bellhallah	151	Sawtooth
2	Rhodes E Piano	92	Metal Clank	152	Dull Sawtooth
5	Voices	93	TimbaleShell Atk	153	Very Dull Saw
6	Ensemble Strings	94	Cowbell Atk	154	Square Wave
7	Elec Jazz Guitar	95	Timbale Atk	155	Dull Square
8	Acoustic Guitar	96	Bell Attack	156	Very Dull Square
10	Electric Bass	97	Clave Atk	157	Buzzy Square
14	Flute	98	Wood Bar Atk	158	Buzz Wave
15	Tenor Saxophone	99	Conga Tone Atk	159	Hi Formant Wave
17	Trumpet/Trombone	100	Conga Slap Atk	160	PrimeNumber Wave
39	Ride Rim Cymbal	101	Elec Pno Atk	161	Triangle Wave
40	Ride Bell Cymbal	102	Brass Attack	162	Third Wave
41	Crash Cymbal	103	Bow Attack	163	Sine Wave
42	Closed Hihat	104	Jazz Guitar Atk	164	ExtDynPrtls1
43	Slr Open Hihat	105	Steel Guitar Atk	165	ExtDynPart2
44	Open Hihat	106	Perc Atk	166	ExtDynSaw
45	Open>Close Hihat	109	Wood Bars		
46	Foot Close Hihat	110	Solo Strings	168	Silence
47	Dry Kick 1	111	Six String Mutes	174	Single Mute
48	Dry Kick 2	112	Oboe Wave	175	Fingered Bass
49	Amb Kick 1	113	Clav Wave	176	Syn Bass Pick
50	Amb Kick 2	114	Elec Piano Wave	177	Syn Bass Slap
51	Amb Kick 3	115	Bell Wave	178	Syn Guitar
52	DrySnare1Soft	116	Ping Wave	179	Perc Voice
53	DrySnare1Hard	117	Drawbars 1-3	180	Syn Piano
55	Dry Snare 2	118	Drawbars 1-4	181	Kick/Snare Loop
56	Dry Snare 3	119	Drawbars1-3 Dist	182	Dry Kick Loop
57	Ambient Snare 1	120	Full Drawbars	183	Amb Kick Loop
58	Ambient Snare 2	121	"Drawbars 1-4,8"	184	Clave/Shakr Loop
59	Ambient Snare 3	122	Organ Wave 1	185	Xstick Loop
60	Cross Stick	123	Organ Wave 2	186	Handclap Loop
62	10in Dry Tom	124	Organ Wave 3	187	Hat Loop
63	12in Dry Tom	125	Organ Wave 4	199	Silence
64	15in Dry Tom	126	Organ Wave 5	770	StereoPiano b0
65	13in Amb Tom	127	Organ Wave 6	771	StereoPiano e1
66	15in Amb Tom	128	Organ Wave 7	772	StereoPiano a1
67	16in Amb Tom	129	Partials 1-3	773	StereoPiano d2
68	Revs Ride Rim	130	Partials 4-7	774	StereoPiano a#2
69	Revse Ride Bell	131	Partials 8-12	775	StereoPiano d3
71	Bidir Amb Kick 1	132	Partials 13-20	776	StereoPiano a3
72	Revs Amb Snre 3	133	Partials 21-30	777	StereoPiano c#4
73	Conga Bass	134	Partials 1&2	778	StereoPiano f4
74	Conga Slap	135	Partials 3&4	779	StereoPiano b4
75	Conga Tone	136	Partials 5-7	780	StereoPiano f5
77	Timbale	137	Partials 8-10	781	StereoPiano b5
78	Timbale Shell	138	Partials 11-15	782	StereoPiano e6
79	Cabasa	139	Partials 16-21	783	StereoPiano a6
80	Clave	140	Partials 2-4	784	StereoPiano a6NR
81	Cowbell	141	"Partials5,7,9,11"	785	StereoPiano e7
82	Tambourine	142	"Partials 1,2,4"	786	Piano Left
83	Handclaps	143	"Partials 1,2,4,6"	787	Piano Right
84	Revs Crash	144	Partials 3-5		
85	Rvs Closed Hihat	145	Partials 1&3		
86	Revs Open Hihat	146	"Partials 1,3,5"		
87	Rvrs Op Hat loop	147	Partials 1&4		
88	Chiff	148	Partials 1&6		
89	Chirp	149	Partials 1&8		
90	FM Bell Trans	150	Partials 1&12		

FX Presets

1	NiceLittleBooth	71	Predelay Hall	151	Chorus Comeback	721	ChorusMedChamber
2	Small Wood Booth	72	Sweeter Hall	152	Chorusier	722	Vanilla ChorRvb
3	Natural Room	73	The Piano Hall	153	Ordinary Chorus	723	Chorus Slow Hall
4	PrettySmallPlace	74	Bloom Hall	154	SlowSpinChorus	724	SoftChorus Hall
5	Sun Room	75	Recital Hall	155	Chorus Morris	725	ChorBigBrnPate
6	Soundboard	76	Generic Hall	156	Everyday Chorus	726	Chorus Air
7	Add More Air	77	Burst Space	157	Thick Chorus	727	Chorus HiCeiling
8	Standard Booth	78	Real Dense Hall	158	Soft Chorus	728	Chorus MiniHall
9	A Distance Away	79	Concert Hall	159	Rock Chorus	729	CathedralChorus
10	Live Place	80	Standing Ovation	160	Sm Stereo Chorus	730	PsiloChorusHall
11	Viewing Booth	81	Flinty Hall	161	Lg Stereo Chorus	731	GuitarChorLsrDelay
15	BrightSmallRoom	82	HighSchool Gym	170	Big Slow Flange	732	Flange + Delay
16	Bassy Room	83	My Dreamy 481!!	171	Wetlip Flange	733	ThroatyFlangeDelay
17	Percussive Room	84	Deep Hall	172	Sweet Flange	734	Flange + 4Tap
18	SmallStudioRoom	85	Immense Mosque	173	Throaty Flange	735	Bap ba-da-dap
19	ClassRoom	86	Dreamverb	174	Delirium Tremens	736	Slapback Flange
20	Utility Room	87	Huge Batcave	175	Flanger Double	737	Quantize+Flange
21	Thick Room	95	Classic Plate	176	Squeeze Flange	738	FlangeDelayHall
22	The Real Room	96	Weighty Platey	177	Simply Flange	739	FlangeDelayRoom
23	Sizzly Drum Room	97	Medm Warm Plate	178	Analog Flanger	740	SloFlangeDelayRoom
24	Real Big Room	98	Bloom Plate	190	Circles	741	FlangeDelayBigHall
25	The Comfy Club	99	Clean Plate	191	Slow Deep Phaser	742	Flange Theatre
26	Spitty Drum Room	100	Plate Mail	192	Manual Phaser	743	FlangeVerb Clav
27	Stall One	101	RealSmoothPlate	193	Vibrato Phaser	744	FlangeVerb Gtr
28	Green Room	102	Huge Tight Plate	194	ThunderPhaser	745	Flange Hall
29	Tabla Room	103	BigPredelayPlate	195	Saucepan Phaser	746	Flange Booth
30	Large Room	110	L:SmlRm R:LrgRm	196	Static Phaser	747	Flange->LaserDelay
31	Platey Room	111	L:SmlRm R:Hall	199	No Effect	748	FlangeTap Synth
40	SmallDrumChamber	112	Gated Reverb	700	Chorus Delay	749	Lazertag Flange
41	Brass Chamber	113	Gate Plate	701	Chorus PanDelay	750	Flange->Pitcher
42	Sax Chamber	114	Exponent Booth	702	Doubler & Echo	751	Flange->Shaper
43	Plebe Chamber	115	Drum Latch1	703	Chorus VryLngDelay	752	Shaper->Flange
44	In The Studio	116	Drum Latch2	704	FastChorusDouble	753	Warped Echoes
45	My Garage	117	Diffuse Gate	705	BasicChorusDelay	754	L:Flange R:Delay
46	School Stairwell	118	Acid Trip Room	706	MultiTap Chorus	755	StereoFlamDelay
47	JudgeJudyChamber	119	Furbelows	707	ThickChorus no4T	756	2Delays Ch Fl Mono
48	Bloom Chamber	120	Festoons	708	Chorused Taps	757	LaserDelay->Rvb
55	Grandiose Hall	121	Reverse Reverb	709	Chorus Slapbacks	758	Shaper->Reverb
56	Elegant Hall	122	Reverse Reverb 2	710	MultiEchoChorus	759	MnPitcher+Chorus
57	Bright Hall	130	Guitar Echo	711	ChorusDelayHall	760	MnPitcher+Flange
58	Ballroom	131	Stereo Echoes1	712	ChorDelayRvb Lead	761	Pitcher+Chor+Delay
59	Spacious Hall	132	Stereo Echoes2	713	ChorDelayRvb Lead2	762	Pitcher+Flng+Delay
60	Classic Chapel	133	4-Tap Delay	714	Fluid ChorDelayRvb	763	SubtleDistortion
61	Semisweet Hall	134	OffbeatFlamDelay	715	ChorLite DelayHall	764	Synth Distortion
62	Pipes Hall	135	8-Tap Delay	716	ChorusSmallRoom	765	Dist Cab EPiano
63	Reflective Hall	136	Spectral 4-Tap	717	DeepChorDelayHall	766	Distortion+EQ
64	Smooth Hall	137	Astral Taps	718	Chorus PercHall	767	Burnt Transistor
65	Splendid Palace	138	SpectraShapeTaps	719	Chorus Booth	768	TubeAmp DelayChor
66	Pad Space	150	Basic Chorus	720	ClassicEP ChorRm	769	TubeAmp DelayChor2
67	Bob'sDiffuseHall					770	TubeAmp DelayFlinge
68	Abbey Piano Hall						
69	Short Hall						
70	The Long Haul						

Standard K2600 ROM Objects

FX Presets

771	TubeAmp Flange	831	Stereo Flanger	911	EQ Morpher
772	PolyAmp Chorus	832	Stereo Delay	912	Mono EQ Morpher
773	PolyAmp DelayFlnge	833	4-Tap Delay	913	Ring Modulator
774	VibrChor Rotors	834	Chorus Delay	914	PitcherA
775	SlightDistRotors	835	Flange Delay	915	PitcherB
776	Rotostort	836	Chorus 4-Tap	916	SuperShaper
777	VibrChor Rotors2	837	Flange 4 Tap	917	SubtleDrumShape
778	Full VbCh Rotors	838	Chorus Echo	918	3 Band Shaper
779	KB3 FXBus	839	Chorus Echoverb	919	LaserVerb
780	KB3 AuxFX	840	Fast Flange	920	Laserwaves
781	Pitch Spinner	841	Wash	921	Crystallizer
782	VibrChrDstRotor1	842	Into The Abyss	922	Spry Young Boy
783	VibrChrDstRotor2	843	Space Flanger	923	Cheap LaserVerb
784	VibChrDstRotor3	844	Flange Room	924	Drum Neurezonate
785	FullVbChTubeRotr	845	Predelay Hall	925	LazerfazerEchoes
786	ChorDelayHall 2	846	Flange Echo	926	Simple Lazerverb
787	Flange Hall 2	847	Rotary Club	927	TripFilter
788	SpeeChorusDeep	848	Rotary Hall	950	HKCompressor 3:1
789	Fluid Wash	849	Chorus	951	DrumKompres 5:1
790	VC+DistRotor	850	Soundbrd/rvb	952	SK FB Compr 6:1
800	Sweet Hall	851	Percussive Room	953	SKCompressor 9:1
801	Small Hall	852	Brt Empty Room	954	SKCompressr 12:1
802	Medium Hall	853	Mosque Room	955	Compress w/SC EQ
803	Large Hall	854	New Gated	956	Compress/Expand
804	Big Gym	855	Chorus Slap Room	957	Compr/Expnd +EQ
805	Bright Plate 1	856	Chorus Bass Room	958	Reverb>Compress
806	Opera House	857	New Chorus Hall	959	Reverb>Compress2
807	Live Chamber	858	Spacious	960	Drum Compr>Rvb
808	Bathroom	859	Wash Lead	961	Expander
809	Med Large Room	860	New Hall Wet/Dryelay	962	3Band Compressor
810	Real Room	861	Rich Delay	963	Simple Gate
811	Drum Room	862	Glass Delay	964	Gate w/ SC EQ
812	Small Dark Room	863	Real Plate	965	Graphic EQ
813	Small Closet	864	Real Niceverb	966	5 Band EQ
814	Add Ambience	865	ClassicalChamber	967	ContourGraphicEQ
815	Gated Reverb	866	Empty Stage	968	Dance GraphicEQ
816	Reverse Reverb	867	Long & Narrow	969	OldPianoEnhancer
817	Non-Linear	868	Far Bloom	970	3 Band Enhancer
818	Slapverb	869	Floyd Hall	971	3 Band Enhancer2
819	Full Bass	870	With A Mic	972	Extreem Enhancer
820	Room + Delay	900	Basic Env Filter	973	Tremolo
821	Delay Big Hall	901	Phunk Env Filter	974	Dual Panner
822	Chorus Room	902	Synth Env Filter	975	SRS
823	Chorus Smallhall	903	Bass Env Filter	976	Widespread
824	Chorus Med Hall	904	EPno Env Filter	977	Mono->Stereo
825	Chorus Big Hall	905	Trig Env Filter	978	3 Band Compress
826	Chor-Delay Room	906	LFO Sweep Filter	979	Simple Panner
827	Chor-Delay Hall	907	DoubleRiseFilter	980	Big Bass EQ
828	Flange-Delay Room	908	Circle Bandsweep	998	Stereo Analyze
829	Flange-Delay Hall	909	Resonant Filter	999	FX Mod Diag
830	Stereo Chorus	910	Dual Res Filter		

FX Algorithms

1	MiniVerb	721	MonoPitcher+Flan
2	Dual MiniVerb	722	Pitcher+Chor+Delay
3	Gated MiniVerb	723	Pitcher+Flan+Delay
4	Classic Place	724	Mono Distortion
5	Classic Verb	725	MonoDistort+Cab
6	TQ Place	726	MonoDistort + EQ
7	TQ Verb	727	PolyDistort + EQ
8	Diffuse Place	728	StereoDistort+EQ
9	Diffuse Verb	729	TubeAmp<>MD>Chor
10	OmniPlace	730	TubeAmp<>MD>Flan
11	OmniVerb	731	PolyAmp<>MD>Chor
12	Panaural Room	732	PolyAmp<>MD>Flan
13	Stereo Hall	733	VibChor+Rotor 2
14	Grand Plate	734	Distort + Rotary
15	Finite Verb	735	KB3 FXBus
130	Complex Echo	736	KB3 AuxFX
131	4-Tap Delay	737	VibChor+Rotor 4
132	4-Tap Delay BPM	738	VC+Dist+1Rotor 2
133	8-Tap Delay	739	VC+Dist+HiLoRotr
134	8-Tap Delay BPM	740	VC+Tube+Rotor 4
135	Spectral 4-Tap	900	Env Follow Filt
136	Spectral 6-Tap	901	TrigEnvelopeFilt
150	Chorus 1	902	LFO Sweep Filter
151	Chorus 2	903	Resonant Filter
152	Dual Chorus 1	904	Dual Res Filter
153	Dual Chorus 2	905	EQ Morpher
154	Flanger 1	906	Mono EQ Morpher
155	Flanger 2	907	Ring Modulator
156	LFO Phaser	908	Pitcher
157	LFO Phaser Twin	909	Super Shaper
158	Manual Phaser	910	3 Band Shaper
159	Vibrato Phaser	911	Mono LaserVerb
160	SingleLFO Phaser	912	LaserVerb Lite
700	Chorus+Delay	913	LaserVerb
701	Chorus+4Tap	950	HardKneeCompress
702	Chorus<>4Tap	951	SoftKneeCompress
703	Chor+Delay+Reverb	952	Expander
704	Chorus<>Reverb	953	Compress w/SC EQ
705	Chorus<>LasrDelay	954	Compress/Expand
706	Flange+Delay	955	Comp/Exp + EQ
707	Flange+4Tap	956	Compress 3 Band
708	Flange<>4Tap	957	Gate
709	Flan+Delay+Reverb	958	Gate w/ SC EQ
710	Flange<>Reverb	959	2 Band Enhancer
711	Flange<>LasrDelay	960	3 Band Enhancer
712	Flange<>Pitcher	961	Tremolo
713	Flange<>Shaper	962	Tremolo BPM
714	Quantize+Flange	963	AutoPanner
715	Dual MovDelay	964	Dual AutoPanner
716	Quad MovDelay	965	SRS
717	LasrDelay<>Reverb	966	Stereo Image
718	Shaper<>Reverb	967	Mono -> Stereo
719	Reverb<>Compress	968	Graphic EQ
720	MonoPitcher+Chor	969	Dual Graphic EQ
		970	5 Band EQ
		998	FXMod Diagnostic
		999	Stereo Analyze

Program Control Assignments

ID	Name		
1	Concert Piano 1	MIDI 25	(Aux) Hall Level+Time
		MIDI 29	Soundboard Wet/Dry
			Soft Pedal is active
2	Stereo Solo Pno	Data	InEQ: Treb
		MIDI 25	(Aux) Hall Level+Time
		MIDI 29	Soundboard Wet/Dry
			Soft Pedal is active
3	Brt Concert Pno	Data	InEQ: Treb
		MIDI 25	(Aux) Hall Level+Time
		MIDI 29	Soundboard Wet/Dry
			Soft Pedal is active
4	Rok Piano	MIDI 25	Room Wet/Dry
		MIDI 26	(Aux) Hall Level
		MIDI 27	Hall Time
5	Piano for Lyrs	MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 29	Soundboard Wet/Dry
6	DrkPno^ArakisPno	MWheel	Vibrato (ArakisPno)
		Data	Toggle: DrkPno ^ ArakisPno
		MIDI 22	detune
		MIDI 25	(Aux) Chorus/Plate Level + Wet/Dry
		MIDI 26	Plate Time
		MIDI 27	Chorus FB
		MIDI 28	Chorus Mix
		MPress	Vibrato (ArakisPno)
7	Honky-Tonk	MWheel	Tremolo
		MIDI 25	(Aux) Hall Time
		MIDI 26	(Aux) Chorus Mix
		MIDI 27	Chorus FB
		MIDI 28	(Aux) Delay Mix
		MIDI 29	Delay Time adj
8	Pno&Syn/AcString	MWheel	String Balance
		Data	String Balance
		MIDI 22	Toggle: SynStrings/AcStrings
		MIDI 25	"(Aux) Hall Level, Room Wet/Dry(Layer 1 pno)"
		MIDI 26	Room Time
		MIDI 27	"EQ Treb boost, SRS Space"
		MIDI 28	"(Aux) Hall, Room HFDamp"
9	ClassicPiano&Vox	MWheel	Vox Level
		Data	"Vox Balance, Piano Treb boost"
		MIDI 22	Vox EQ Bass
		MIDI 23	"Vox EQ Treb, St Image Mix"
		MIDI 25	"(Aux) Hall Level, Room Wet/Dry"
		MIDI 26	Room and Hall Times
		MIDI 27	St Image In Gain
		MIDI 28	St Image CenterGain
10	E Grand Stack	MIDI 29	Vox St Image L/R Delay
		MWheel	String Level
		Data	InEQ: Treb boost
		MIDI 25	"(Aux) Room Level, (Aux) FDR Wet/Dry"
		MIDI 26	Flange Mix
		MIDI 27	Flange Tempo
	MIDI 28	Enhc Lo/Mid Drive	
	MIDI 29	FDR Delay Mix adj	

ID	Name		
11	Piano D'Biggy	MWheel	Vibrato
		Data	"BandPass adj, EnvCtl: Rel"
		MIDI 22	(Aux) Chorus Mix
		MIDI 23	(Aux) Delay Mix
		MIDI 24	Delay FB
		MIDI 25	(Aux) Hall Mix
		MIDI 26	Hall dry Mix+Time
		MIDI 27	InEQ: Treb
		MIDI 28	InEQ: Bass
		MIDI 29	Chorus Pitch Env adj
12	DynEPiano^EPnoPF	MWheel	Tremolo/ Vibrato
		Data	"Toggle: DynEPiano ^ EPnoPF, Chorus LFODepth+Rate, (Aux) Plate Level cut+PreDelay adj"
		MIDI 22	Chorus Wet/Dry
		MIDI 23	Chorus LFODepth
		MIDI 24	Chorus Xcouple
		MIDI 25	(Aux) Plate Wet/Dry+Decay Time
		MIDI 26	Plate Room Size
		MIDI 27	Chorus FB
		MIDI 28	Chorus Tap Level
		MIDI 29	Chorus Rate adj
13	FM-ish E-Piano	MWheel	"Layer detune, Vibrato, Saw+Shp detune"
		Data	Layer Enable
		MIDI 22	Layer detune
		MIDI 23	Layer octave shift
		MIDI 24	"Layer detune, Saw+Shp detune"
		MIDI 25	"CDR Wet/Dry, (Aux) Hall Wet/Dry+Time"
		MIDI 26	"Enhc Xover, Chorus Wet/Dry"
		MIDI 27	Chorus FB and Rate
		MIDI 28	CDR Chorus Depth
		14	Suitcase E Piano
Data	Tremelo Rate		
MIDI 25	(Aux) Room Level		
MIDI 26	Enhc Level		
MIDI 27	Flange Wet/Dry		
MIDI 28	"Enhc Hi Drive, Flange FB"		
MIDI 29	"Toggle: Enhc + Flange, EQ: Treb"		
BreathCtl	LoPass Freq and Res		
MWheel	Tremolo ^ Filt and Res Depth		
Data	Toggle: PhunkEPno ^ FonkMW		
15	PhunkEPno^FonkMW	MIDI 22	Notch Filt Freq ^ Tremolo
		MIDI 23	"InEQ: Treb boost, Lowpass Depth ^ Tremelo Rate"
		MIDI 24	"Chrous Level, Notch Width ^ EnvCtl"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	4Tapap Wet/Dry
		MIDI 28	4Tapap FB
		MIDI 29	4Tapap I/O

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
16	Clavinators 1^2	MWheel	detune/ LFO
		Data	"Toggle: Clavinators1 ^ 2 , EnvCtl: Att+Dec (Layer 8)"
		MIDI 22	"Layer Enable, Band/Lo/HiPass adj, Shaper amt"
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	"EnvCtl: Rel, (Aux) Hall Time"
		MIDI 25	Chorus FB
		MIDI 26	Chorus Rate+Depth
		MIDI 27	Delay Mix
		MIDI 28	Delay Time
		MIDI 29	Toggle: Room I/O
17	Spaceychord 1^2	MWheel	"Vibrato, Phaser LFO/Ctr Freq"
		Data	Toggle: Spaceychord 1 ^ 2
		MIDI 22	"SP4Tap Wet/Dry, Bass Freq+Res+boost"
		MIDI 23	"4Tap FB, BandPass Freq adj"
		MIDI 24	"4Tap Tempo, EnvCtl: Rel"
		MIDI 25	ChorDelay Wet/Dry
		MIDI 26	(Aux) Phase Notch
		MIDI 27	Phase FB
		MIDI 28	4Tap FB Image
		MIDI 29	Phase Level adj
18	DaNU Clavs 1^2^3	MWheel	Layer balance
		Data	Toggle: DaNU Clavs 1 ^ 2 ^ 3
		MIDI 22	Flange Wet/Dry
		MIDI 23	Flange LFO Level
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	(Aux) Chorus Slapback Level
		MIDI 26	Chorus Mix
		MIDI 27	"Flange Tempo, FB"
		MIDI 29	"Toggle: Dist/ Flange, Layer balance"
19	VAST B3! SW2+CC2	MWheel	Drawbar 9
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	Drawbar 3
		MIDI 24	"Drawbar 4, EnvCtl: Imp"
		MIDI 25	Drawbar 5
		MIDI 26	Drawbar 6
		MIDI 27	Drawbar 7
		MIDI 28	EnvCtl: Imp
		MIDI 29	Toggle: Vib/Chorus I/O
20	Rock Organ	Breath	"(Aux) Plate Level, Dist Drive+adj, EQ Bass+Treb"
		PWheel	Leslie Depth
		MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, "
		MIDI 24	"Drawbar 4, (Aux) Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
MIDI 28	Plate Level		
MIDI 29	Toggle: VibeChorus I/O		

ID	Name		
21	Ballad Organ	MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, (Aux) Plate Level"
		MIDI 24	"Drawbar 4, Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Cabinet Dist Drive+Lopass
		MIDI 29	Toggle: VibeChorus I/O
22	Gospel Organ	MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, (Aux) Plate Level"
		MIDI 24	"Drawbar 4, Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Cabinet Dist Drive + Lopass adj
		MIDI 29	Toggle: VibeChorus I/O
23	OverDrive Organ	MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, (Aux) Plate Level"
		MIDI 24	"Drawbar 4, Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Cabinet Dist Drive+Lopass adj
		MIDI 29	Toggle: VibeChorus I/O
24	Perc Organ	MWheel	Leslie Depth
		Data	Drawbar 1
		MIDI 22	Drawbar 2
		MIDI 23	"Drawbar 3, (Aux) Plate Level"
		MIDI 24	"Drawbar 4, Plate Time"
		MIDI 25	KeyClick
		MIDI 26	Perc Harmonic (Hi/Low)
		MIDI 27	"HFDamp, Perc Decay"
		MIDI 28	Cabinet Dist Drive+Lopass adj
		MIDI 29	Toggle: VibeChorus I/O
25	Chiffy Pipes	MWheel	Decrescendo
		Data	LoPass Freq
		MIDI 22	Key Click
		MIDI 23	Vibrato
		MIDI 25	(Aux) Hall Level+Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall Early Ref Level
		MIDI 29	"Toggle: Chorus I/O, Hall HFDamp+PreDelay"
		MPress	Vibrato
		26	Offertory
Data	LoPass Freq		
MIDI 22	Layer Balance		
MIDI 23	InEQ: Treb boost		
MIDI 24	EnvCtl: Rel		
MIDI 25	(Aux) Hall Level		
MIDI 26	Hall Wet/Dry		
MIDI 27	Hall Time		
MIDI 28	Hall EarlyRefLevel		
MIDI 29	"Chorus I/O, EQ Mid"		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name				
27	Pedal Pipes	MWheel	"DecRescendo, Slight Vibrato"		
		Data	Layer Balance		
		MIDI 25	(Aux) Hall Level+Wet/Dry		
		MIDI 26	Hall Time		
		MIDI 27	Hall EarlyRefLevel		
		MIDI 28	Chorus FB		
		MIDI 29	"Chorus I/O, Hall adj"		
28	Church Organ	MWheel	Vibrato		
		Data	Layer 1 Xfade		
		MIDI 22	Layer Balance		
		MIDI 23	Layer Balance		
		MIDI 25	(Aux) Hall Wet/Dry		
		MIDI 26	Hall Time		
		MIDI 27	Hall EarlyRefLevel		
		MIDI 29	Toggle: Hall Mix		
		MPress	Vibrato		
29	DualBass^SlpBass	MWheel	Vibrato		
		Data	Toggle: DualBass + SlpBass		
		MIDI 22	"EnvCtl: Dec, BandPass adj, ParaTreb"		
		MIDI 23	EnvCtl : Att+Imp		
		MIDI 24	EnvCtl: Rel		
		MIDI 25	(Aux) Room Level+Time		
		MIDI 26	Phaser Notch/ BP ^ Enhc LoDrive+Delay		
		MIDI 27	Phaser Center Freq L ^ Enhc Hi Mix		
		MIDI 28	Phaser Center Freq R ^ Enhc Mid Mix		
		MIDI 29	Phaser FB boost * Enhc Crossover Freq		
30	Warm Bases	MWheel	Vibrato		
		Data	Toggle: Layers		
		MIDI 22	"LoPass adj, Shaper amt, EnvCtl: Imp+Att"		
		MIDI 23	"EnvCtl: Imp, ParaBass+HighPass Freq"		
		MIDI 24	"EnvCtl: Rel, InEQ: Bass"		
		MIDI 25	(Aux) Room Level		
		MIDI 26	Room Absorption		
		MIDI 27	Comp Ratio		
		MIDI 28	Comp: Att+Rel Time		
		MIDI 29	add EQ Morph		
		MPress	Vibrato		
		31	SustBass^MixBass	MWheel	"Vibrato, LoPass Freq"
				Data	Toggle: SustBass + MixBass
MIDI 22	"BandPass Freq+Width, EnvCtl: Imp, LoPass adj"				
MIDI 23	EnvCtl: Rel				
MIDI 24	In EQ: Bass				
MIDI 25	Comp Att Time				
MIDI 26	Comp Rel Time				
MIDI 27	Comp Ratio				
MIDI 28	Comp ThReshold				
MIDI 29	"Toggle: Comp I/O, (Aux) Room I/O"				
MPress	Vibrato				

ID	Name				
32	RickenBass	MWheel	Vibrato		
		Data	Layer Enable		
		MIDI 22	Bass Cut		
		MIDI 23	EnvCtl: Att+Dec		
		MIDI 24	EnvCtl: Rel		
		MIDI 25	(Aux) Hall Level		
		MIDI 26	"Flange Wet/Dry, Chorus Wet/Dry"		
		MIDI 27	"Flange FB+Level, Chorus FB"		
		MIDI 28	"Flange L/R phase, Chorus Rate"		
		MIDI 29	Toggle: Flange + Chorus		
		MPress	Vibrato		
		33	Synth Fretless	MWheel	"Vibrato,"
				Data	"Shaper amt, HiPass Freq"
MIDI 22	InEQ: Bass				
MIDI 23	EnvCtl: Imp				
MIDI 24	EnvCtl: Rel				
MIDI 25	(Aux) Hall Level				
MIDI 26	"Flange Wet/Dry, Chorus Wet/Dry"				
MIDI 27	"Flange FB, Chorus FB"				
MIDI 28	"Flange L/R Phase, Chorus Rate"				
MIDI 29	Toggle: Flange + Chorus				
MPress	"Vibrato, Shaper adj, Flange Wet/Dry"				
34	Moogy Bass 1^2	MWheel	Vibrato		
		Data	Toggle: Moogy Bass 1 ^ 2		
		MIDI 22	"LoPass Filt adj, EnvCtl: Att"		
		MIDI 23	EnvCtl: Imp		
		MIDI 24	EnvCtl: Rel		
		MIDI 25	(Aux) Place Level		
		MIDI 26	"Flange Wet/Dry(sys), Stlmg EQ Bass"		
		MIDI 27	"Flange FB, Stlmg CenterGain"		
		MIDI 28	"Place HFDamp, Flange HFDamp, Stlmg L/R Delay"		
		MIDI 29	Toggle: Flange + Widespread (Stlmg)		
MPress	Vibrato				
35	Moogy Bass 3^4	MWheel	Vibrato		
		Data	Toggle: Moogy Bass 3 ^ 4		
		MIDI 22	"LoPass Freq, EnvCtl: Imp"		
		MIDI 23	LoPass Res		
		MIDI 24	EnvCtl: Imp+Rel		
		MIDI 25	"(Aux) Chorus Level+Wet/Dry, (fx2) Room Cut"		
		MIDI 26	"(fx2)Chorus Mix, Enhc Crossover 1"		
		MIDI 27	"Chorus FB, Enhc Crossover 2"		
		MIDI 28	"Room HFDamp, Enhc Drive adj"		
		MIDI 29	Toggle: ChorVerb + Enhc; Enhc Lo+Mid+Hi Drive		
		MPress	Vibrato		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
36	Matrix Big Bass	MWheel	Vibrato
		Data	Layer Toggle
		MIDI 22	"EnvCtl: Imp+Att, LoPass adj"
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level+HFDamp
		MIDI 26	"Flange Wet/Dry, Tube Drv"
		MIDI 27	"Flange LFO period, MDelay Wet/Dry"
		MIDI 28	"Flange FB, MDelay FB, Dist Warmth"
		MIDI 29	Toggle: Flange + TubeAmpDelayCh
		MPress	Vibrato
		37	Pitt Bass mono 1^2
Data	"Layer Enable, EnvCtl: Rel"		
MIDI 22	"PWM Filt+Width adj, EnvCtl: Att+Dec, ParaBass Frq"		
MIDI 23	"InEQ: Bass, EnvCtl: Imp"		
MIDI 24	"InEQ: Treb, EnvCtl: Rel"		
MIDI 25	(Aux) Chamber Mix		
MIDI 26	Chamber HFDamp+Time		
MIDI 27	Chorus FB		
MIDI 28	Delay Mix		
MIDI 29	Chorus Depth		
MPress	Vibrato		
38	Punch Bass 1^2	MWheel	"Vibrato, LoPass Res"
		Data	Toggle: Punch Bass 1 ^ 2
		MIDI 22	InEQ: Bass
		MIDI 23	EnvCtl: Imp+Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Chamber Mix+Level+Time+HFDamp
		MIDI 26	InEQ: Treb
		MIDI 27	Chorus FB
		MIDI 28	Chorus Depth
		MIDI 29	Flange I/O
		MPress	Vibrato
		39	Tee Bee This MW
Data	LoPass Res		
MIDI 22	EnvCtl: Imp		
MIDI 23	EnvCtl: Att		
MIDI 24	EnvCtl: Rel		
MIDI 25	(Aux) Hall Level+adj		
MIDI 26	Chorus Wet/Dry		
MIDI 27	Chorus FB		
MIDI 28	Chorus Tap Pan		
MIDI 29	add Enhc		
MPress	Vibrato		
40	BottomFeed^Pulse	MWheel	Vibrato
		Data	Toggle: BottomFeed ^ Pulse
		MIDI 22	"LoPass Gate+Freq, EnvCtl: Imp+Att"
		MIDI 23	"EnvCtl: Att+Dec, Saw Pitch adj"
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Room Level, (FX3)Hall Mix"
		MIDI 26	Chorus Mix
		MIDI 27	Chorus Rate
		MIDI 28	Chorus FB
		MIDI 29	Toggle: Chorus(4Tap) + Flange
MPress	Vibrato		

ID	Name		
41	SkoolBass^Simple	MWheel	Vibrato
		Data	Toggle: SkoolBass ^ Simple
		MIDI 22	"Pulse Width+Freq, Pitch adj, EnvCtl: Imp+Att"
		MIDI 23	"Dist Drive adj, EnvCtl: Dec"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	"Phase Notch/ Dry, Dist Wet/Dry"
		MIDI 27	"Phase Center Freq, Dist Drive adj"
		MIDI 28	"Phase LFO Depth, Dist Bass adj"
		MIDI 29	"Toggle: Phase + Dist, Room Time adj"
		MPress	Vibrato
		AttVel	LoPass gate
GKeyNum	L/R Phase		
42	MonoBass^FixBass	MW	Vibrato
		Data	"Toggle: MonoBass ^ FixBass, BandPass Width"
		MIDI 22	"LoPass Freq, ^ Notch Freq+Width, EnvCtl: Imp"
		MIDI 23	"InEQ: Bass, EnvCtl: Att"
		MIDI 24	"InEQ: Treb, Hall HFDamp, EnvCtl: Rel"
		MIDI 25	(Aux) CDR Level+Hall Time
		MIDI 26	Delay Mix
		MIDI 27	Phaser FB Cut
		MIDI 28	"Phaser LFO Rate, Hall Mix"
		MIDI 29	"Chorus-Delay Cut, Phase Notch adj"
MPress	Vibrato		
43	Ravelike Bass	MWheel	Vibrato
		Data	Later Enable
		MIDI 22	"LoPass Res, EnvCtl: Att"
		MIDI 23	"InEQ: Bass, EnvCtl: Imp"
		MIDI 24	"InEQ: Treb, EnvCtl: Dec+Rel"
		MIDI 25	(Aux) Room Level
		MIDI 26	Flange Mix (sys)
		MIDI 27	"Pitcher Mix, LsrDelay HFDamp"
		MIDI 28	"Pitcher Pitch, LsrDelay Time"
		MIDI 29	Toggle: Laserverb I/O
MPress	Vibrato		
44	Junosis^Geo-Bass	MWheel	Oscillator Vibrato
		Data	"LoPass Freq, Layer Enable"
		MIDI 22	LoPass Res
		MIDI 23	"Pitch Env, EnvCtl: Rel"
		MIDI 24	EnvCtl: Imp
		MIDI 25	EnvFilt Wet/Dry
		MIDI 26	EnvFilt Min Freq
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	Toggle: (Aux) SweepFilt I/O
MPress	Sweep Res		
PWheel	(+/-) 2 octaves		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name				
45	Ace Bass^ChirpBas	MWheel	Vibrato		
		Data	"Toggle: Ace Bass ^ Chirp Bass, LoPass Filt+Res"		
		MIDI 22	"HiPass Freq, LoPass Res, EnvCtl: Imp"		
		MIDI 23	"LoPass Res, EnvCtl: Att"		
		MIDI 24	EnvCtl: Att+Rel		
		MIDI 25	(Aux) Room Level		
		MIDI 26	"Flange Wet/Dry, Chorus Wet/Dry"		
		MIDI 27	"Flange FB, Chorus FB"		
		MIDI 28	"Flange LFO Period, Chorus Tap Delay"		
		MIDI 29	Toggle: Flange + Chorus		
		MPress	Vibrato		
		PW	Octave Shift		
		46	Gritz	MWheel	Vibrato + Shaper Pitch Cut
Data	LoPass Freq				
MIDI 22	LoPass Res				
MIDI 23	"Pitch ASR, EnvCtl: Imp"				
MIDI 24	EnvCtl: Release				
MIDI 25	"(Aux) Room Level, Laser FB"				
MIDI 26	"LsrDelay Time, TubeDrive adj"				
MIDI 27	"LsrDelay Spacing, Tube Warmth"				
MIDI 28	LsrDelay Contour				
MIDI 29	Toggle: LaserDelay + TubeDrive				
MPress	Vibrato				
47	Homey Saw			MWheel	Vibrato
				Data	Pitch
		MIDI 22	"LoPass Res, Freq, Chorus Cut, EnvCtl: Imp"		
		MIDI 23	"InEQ: Bass, EnvCtl: Att+Dec"		
		MIDI 24	"InEQ: Treb, EnvCtl: Rel"		
		MIDI 25	(Aux) Hall Level		
		MIDI 26	Chorus FB		
		MIDI 27	Delay Mix		
		MIDI 28	Delay Time		
		MIDI 29	Hall Decay Time+Room size		
		MPress	Vibrato		
		48	OG	MWheel	Sync Amp (AClock)
				Data	Sync M Pitch
MIDI 22	Sync S Pitch				
MIDI 23	EnvCtl: Att				
MIDI 24	EnvCtl: Rel				
MIDI 25	(Aux) Plate Level				
MIDI 26	Plate Time+HFDamp				
MIDI 27	Tube Drive				
MIDI 28	MDelay Wet/Dry				
MIDI 29	TubeDelayCh Wet/Dry				
49	Lowdown Bass			MWheel	"Vibrato, HiPass Freq (Chirp)"
				Data	LoPass Gate
				MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att		
		MIDI 24	"Layer Enable, EnvCtl: Dec+Rel"		
		MIDI 25	(Aux) Dist Level		
		MIDI 26	"Dist Drive, Mid EQ cut, Flange Wet/Dry"		
		MIDI 27	"InEQ: Bass, Flange FB"		
		MIDI 28	Cab HiPass		
		MIDI 29	Toggle: EQ + Flange		
		MPress	Vibrato		

ID	Name				
50	SquashStudio Kit	MWheel	AltControl: Toms		
		Data	"Pitch: Kicks, Snares, Toms, HiHats"		
		MIDI 22	Snare Filters		
		MIDI 23	Kick Filters		
		MIDI 24	"EnvCtl: Kicks, Snares, Toms"		
		MIDI 25	"(FX1+2)- (Aux) Room Level+Time, (FX2)- Mix Level "		
		MIDI 26	(FX2) Compressor Ratio+Gain		
		MIDI 27	Room HFDamp		
		MIDI 28	"Toggle: Enhancer HiDrive, Room PreDelay"		
		MIDI 29	Enhancer Hi Delay Time		
		51	Retro Skins MW	MWheel	Multiple Layer Toggle
				Data	Pitch: Kicks
				MIDI 22	Pitch: Snares
MIDI 23	"Filter Freq: Kicks, Toms, Ride, AuxPerc "				
MIDI 24	EnvCtl: Kicks+Snares				
MIDI 25	(FX1+2) Rooms Wet/Dry				
MIDI 26	(Aux) Room Wet/Dry				
MIDI 27	(Aux) Compressor Attack Time				
MIDI 28	(FX1) InEQ: Bass+Treb				
MIDI 29	Toggle: Alien Skin Effect				
52	2 Live Kits 2 MW			MWheel	Multiple Layer Toggle
				Data	"Pitch: Kicks, Toms"
				MIDI 22	Pitch: Snares
		MIDI 23	"HF Stimulator: Cymbal, HiHats"		
		MIDI 24	"EnvCtl: Kicks, Snares, Toms, Cymbal"		
		MIDI 25	"(FX1)-(Aux) Hall Level, (FX2) Plate PreDelay"		
		MIDI 26	(FX2)-(Aux) Hall Level		
		MIDI 27	(FX1) GateRvb Wet/Dry+Gate Threshold		
		MIDI 28	"Hall Time, Plate Wet/Dry"		
		MIDI 29	Toggle: Plate RvbTime boost-Megaverb!		
		53	Garage Kit II MW	MWheel	Multiple Layer Toggle
				Data	"Pitch: Kicks, Toms"
				MIDI 22	"Pitch: Snares, Crash2"
MIDI 23	"EnvCtl: Kicks, Toms"				
MIDI 24	"EnvCtl: Snares, HiHats"				
MIDI 25	(Aux) RoomGate Absorption+Gain				
MIDI 26	(FX3) Compression control				
MIDI 27	(FX3) InEQ: Treb				
MIDI 28	(FX3) InEQ: Bass				
MIDI 29	"Toggle: (Aux) Room type, Lopass adj"				
54	Jazz Kit II			MWheel	Pitch: AuxPerc
				Data	"Pitch: Kicks, Toms"
				MIDI 22	Pitch: Snares
		MIDI 23	"Gain: HiHats, Crash Cym"		
		MIDI 24	"EnvCtl: Kicks, Toms"		
		MIDI 25	(FX1+2) Rooms Wet/Dry+Time		
		MIDI 26	"(FX1+2)- (Aux) Hall Level, (FX2)- Mix Level"		
		MIDI 27	(FX2) In EQ: Treb cut		
		MIDI 28	(Aux) Hall TrebShlf Freq+cut		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
55	Hoppy Kit!	MWheel	"Notchy Filter: Toms, CrossStick"
		Data	"Pitch: Kicks, Toms, HiHats, Cowbell"
		MIDI 22	"Pitch: Snares, Crash1, Ride, Clap, Clave, Tambourine"
		MIDI 23	"Filter: Kicks, Snare2-3, Crash2, Ride; [Impact on Kick2]"
		+MW	"Filter: Snare1, HiHats, Crash1, AuxPerc"
		MIDI 24	"EnvCtl: Toms, Kick1, Snares"
		MIDI 25	"(FX1) Room Wet/Dry, (FX2) Flange Wet/Dry"
		MIDI 26	(Aux) Booth Level
		MIDI 27	Booth Absorption
		MIDI 28	"Room HFDamp, Flange FB"
		MIDI 29	Toggle: Room + Flange
		56	L'il Nipper Kit
Data	"Pitch: Kick, Toms"		
MIDI 22	"Pitch: Snares, AuxPerc"		
MIDI 23	"Filter: Hihats, Cymbals"		
MIDI 24	"EnvCtl: Kicks, Snares"		
MIDI 25	(Aux) Plate Time		
MIDI 26	(FX3) Laserverb Spacing		
MIDI 27	"(FX2) Pitcher Pitch, Pitcher Wet/Dry"		
MIDI 28	Pitcher control		
MIDI 29	Laserverb Delay+Contour+FB		
MPress	AuxPerc Pitch		
57	Geo-Kit MW+22		
		Data	"Pitch: Kicks, Snares, Toms, ""Shaker"""
		MIDI 22	Crossfade to tertiary Kicks; Pitch: Elec. Snare only
		MIDI 23	"Filter: Kicks, Snares, HiHats, Crashes, Ride, ""Shaker"";"
			Amp LFO: SFX (A6-B6)
		MIDI 24	"EnvCtl: most Kicks, Snares, Toms, ""Shaker"" , Elec HiHat"
			LFO Rate: SFX (A6-B6)
		MIDI 25	"(FX3) Mix Level, (Aux) GateRvb Level"
		MIDI 26	"(FX4) Mix Level, GateRvb Level"
		MIDI 27	(FX3) Compressor SmoothTime+MakeUpGain
		MIDI 28	"(FX2) EnvFlt Freq Sweep+Threshold, (FX1) Delay Level"
		MIDI 29	Toggle: Compressor + ChorDelay
58	Lo-Fi Vinyl Kit	MWheel	Pitch for most Needle FX and other SFX
		Data	"Pitch: Kicks, Toms, HiHats"
		MIDI 22	"Pitch: Snares, Crash1"
		MIDI 23	"Assorted Filters: Kick, Toms, Snares,"
			"HiHats, Crashes, Ride (Resonant)"
		MIDI 24	"EnvCtl: Kick, Toms, Snares"
		MIDI 25	(FX1) Booth Wet/Dry
		MIDI 26	(Aux) Hall Level
		MIDI 27	"(FX2) Pitcher Wet/Dry, (FX3) LaserVerb Wet/Dry"
		MIDI 28	"(FX2) Pitcher Pitch, (FX3) LaserVerb Delay"
MIDI 29	Toggle: Pitcher + LaserVerb		

ID	Name		
59	Technoo Kit	MWheel	Alternate Kick (B2-C3)
		Data	Pitch: nearly all elements
		MIDI 22	"Filter: Kicks, AuxPerc"
		MIDI 23	"Filter: Snares, Toms, Ride, Crashes, HiHats (A#1-B1)"
		MIDI 24	"EnvCtl: Kicks, Snares (not G#1-A1), Ride, Choke Cym"
		MIDI 25	(FX1) Gated Reverb Wet/Dry
		MIDI 26	Gated Reverb Time
		MIDI 27	(FX1+2) (Aux) LaserVerb Level
		MIDI 28	(FX4) LaserVerb Level
		MIDI 29	Toggle: GateRvb HFDamp+Gate Threshold
60	VAST Sliders 808	MWheel	"AltStart control, Impact on most elements"
		Data	"Pitch: Kicks, Toms"
		MIDI 22	"Pitch: Snares, NoizeToms"
		MIDI 23	"EnvCtl: Kicks, Toms"
		MIDI 24	"EnvCtl: Snares, HiHats, Crash2, NoizeToms"
		MIDI 25	(FX1) Hall Wet/Dry
		MIDI 26	(FX4)- (Aux) Room Level (dry at very top)
		MIDI 27	"Hall Time, Room Decay Time+HFDamp"
		MIDI 28	"(FX2) Flange Wet/Dry+FB, (FX3) 8-Tap Wet/Dry"
		MIDI 29	"Toggle: 8-Tap I/O (Sys), Room Level adj"
61	Industry Set II	MWheel	Filter Resonance (A#4-C5)
		Data	"AltControl on some layers,"
			Pitch on Kick-like elements and some Toms
		MIDI 22	Various Pitch controls on many elements
		MIDI 23	Filters or Modulation Pitch on many elements
		MIDI 24	EnvCtl: assorted kinds of control on many elements
		MIDI 25	"(FX2) Flange Wet/Dry, InEQ: Bass"
		MIDI 26	"(Aux) Hall Level, (FX2) Mix Level"
		MIDI 27	(FX3) DistEQ Wet/Dry+Gain Adjust
		MIDI 28	Distortion Warmth
MIDI 29	Toggle: RoomType: Hall + Delay		
MPress	Filter Resonance (A#4-C5)		
62	General MIDI Kit	MWheel	"Assorted Filters, on most elements"
		Data	"Pitch: Kicks (B1, C2), and Toms"
		MIDI 22	"Pitch: Snares (D2, E2), HiHats, Ride, Crash (C#3)"
		MIDI 23	"Pitch: Congas, Timbales, many other elements"
		MIDI 24	"EnvCtl / ASR Amp Env: Kicks (above), Snares (above)"
			"Toms, Crashes, Ride, Triangle, Ding (A#1)"
		MIDI 25	(FX1) Room Wet/Dry
		MIDI 26	Room Rvb Time
		MIDI 27	"(Aux) Hall Level, (FX1) Mix Level"
		MIDI 28	(FX1) Compressor Ratio+Threshold+Rel Time
MIDI 29	"Toggle: (FX1) Room+Booth, (Aux) Hall+""Slither Booth"""		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
63	Slam'n Drums2 GM	MWheel	"Lowpass Filter and Filter Env Ctrl, many elements"
		Data	"Pitch: Kicks (B1, C2, D6)"
		MIDI 22	"Pitch: Snares (D2, E2), Toms, HiHats"
		MIDI 23	"Filters: Kicks and Snares (above), Toms; HiHat boost"
		MIDI 24	"EnvCtl / ASR Amp Env: Kicks, Snares, Toms"
		MIDI 25	(FX1) Gated Reverb Wet/Dry+Time+HFDamp
		MIDI 26	(FX2) Sweep Filter Wet/Dry
		MIDI 27	(FX1) FlangeDelay Level (Sys)
		MIDI 28	(FX2) FlangeDelay Level (Sys)
		MIDI 29	Toggle: Sweep Filt direction Rise + Fall
64	EleCroDrumsetGM	MWheel	(FX2) Resonant Filter Freq
		Data	"Filter: Kicks, Toms, assorted other elements"
		MIDI 22	"Pitch: Snares, some Toms, Cymbals,+other elements"
		MIDI 23	"Filter: Snares, Cymbals, HiHats, Synth Boing"
		MIDI 24	EnvCtl: most elements
		MIDI 25	"(FX1) Room Wet/Dry, (FX3) Echo Wet/Dry, (Aux) Hall Wet/Dry+Level"
		MIDI 26	"Room Time, (Aux) Hall Level"
		MIDI 27	Hall Late Rvrb Time
		MIDI 28	(FX3) Delay Feedback (only a few elements)
		MIDI 29	"Toggle: Room + ResFilt, Delay + Room"
65	SmallKit+Perc MW	MWheel	Cowbell + Shaker Enable
		Data	"Pitch: Kit elements (Kick, Snare, HiHats, Toms, Cymbals)"
		MIDI 22	"Pitch: Congas, Timbales, Agogo, Clave, Cowbell (MW)"
		MIDI 23	"Filters: Cabasas, Tambourines, Clave, Agogo, "
			"Timbales, Kick, Snare, HiHats, Toms, Cowbell (MW)"
		MIDI 24	"Pitch+Filter: Cabasas, Shaker (MW), Tambourine (F#3, F#4)"
		MIDI 25	(FX1+2) Rooms Wet/Dry
		MIDI 26	Rooms' Times
		MIDI 27	"(Aux) Plate Level, (FX4) Mix Level, (FX3) Hall Wet/Dry"
		MIDI 28	Plate Time
MIDI 29	Toggle: Room + Hall		
66	Steel Str Guitar	MWheel	Vibrato
		Data	Layer Enable
		MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Chamber Wet/Dry
		MIDI 26	Chamber Time
		MIDI 27	Chamber HFDamp
		MIDI 28	Comp Ratio
		MIDI 29	Toggle: Pitch I/O
MPress	Vibrato		

ID	Name				
67	12-str Guitar	MWheel	Vibrato		
		Data	HFStim EQ		
		MIDI 22	EnvCtl: Imp		
		MIDI 23	EnvCtl: Att		
		MIDI 24	EnvCtl: Rel		
		MIDI 25	(FX1+2) Room Wet/Dry+(FX1) Time		
		MIDI 26	(Aux) Hall Level		
		MIDI 27	Hall Time		
		MIDI 28	Room + Hall HFDamp		
		MIDI 29	Toggle: (fx1+2) Room Reverbs		
		MPress	Vibrato		
		Soft PdI	Active		
		68	Spark Guitar	MWheel	Vibrato
				Data	HFStim adj
MIDI 22	EnvCtl: Imp+Att				
MIDI 23	EnvCtl: Dec				
MIDI 24	EnvCtl: Rel				
MIDI 25	"(fx1) Room Mix, (Aux) Hall Level"				
MIDI 26	Hall PreDelay+Time				
MIDI 27	Delay Mix (sys)				
MIDI 28	Chorus Delay				
MIDI 29	Chorus FB				
MPress	Vibrato				
69	Blue Moods	MWheel	"Slight Vibrato, String Balance"		
		Data	"String Balance, Gtr Hi Freq Cut"		
		MIDI 22	EnvCtl: Imp+Att		
		MIDI 23	EnvCtl: Dec		
		MIDI 24	EnvCtl: Rel		
		MIDI 25	(Aux) Hall Level		
		MIDI 26	Hall Time+HFDamp		
		MIDI 27	"Enhc Lo Mix, Chorus Wet/Dry"		
		MIDI 28	"Enhc Hi Mix+Drive, Chorus FB"		
		MIDI 29	"Toggle: Enhc + Chorus, Hall + Room"		
MPress	Vibrato				
70	SloChrsGtr^Harms	MWheel	Tremolo		
		Data	Toggle: SloChorusGuit ^ Harms		
		MIDI 22	Para EQ (VAST)		
		MIDI 23	"LoPass Res, Chorus (VAST) adj"		
		MIDI 24	"EnvCtl: Dec+Rel, Harm(Sin) Oct Shift"		
		MIDI 25	(Aux) Hall Level		
		MIDI 26	"Hall Time+HFDamp, Chorus Wet/Dry"		
		MIDI 27	"Enhc Lo Mix, Chorus FB"		
		MIDI 28	Enhc Hi Mix+Drive		
		MIDI 29	"Toggle: Enhc + Chorus, Hall + Room"		
MPress	Vibrato				

Standard K2600 ROM Objects

Program Control Assignments

ID	Name				
71	ES335^Abercrombie	MWheel	Notch Filt Tremolo		
		Data	Toggle: ES335 ^ Abercrombie		
		MIDI 22	"Para Mid Freq, ^ Notch Freq"		
		MIDI 23	"Para Mid Amp (ES335), "		
		MIDI 24	"EnvCtl: Att+Rel, ^EnvCtl: Imp+Att"		
		MIDI 25	(Aux) Hall Mix		
		MIDI 26	"Hall HFDamp, InEQ: Bass+Treb (Abercrombie)"		
		MIDI 27	Chorus Mix		
		MIDI 28	Delay Mix		
		MIDI 29	Turns off Semi-Tone Pitch Bend		
		MPress	Vibrato		
		PWheel	Simulates Fretboard Slide (ES335)		
		72	SliderDistJazzGt	MWheel	Vibrato/Tremolo
Data	Enables Dist Gtr Layers				
MIDI 22	"Para EQ ^ Hi Freq Stim Drive, Dist EQ"				
MIDI 23	"EnvCtl: Imp, Dist Drive"				
MIDI 24	EnvCtl: Rel				
MIDI 25	"(Aux) FDR Hall Level, Rvb Time"				
MIDI 26	Flange FB				
MIDI 27	Flange Tempo				
MIDI 28	Delay Mix				
MIDI 29	Delay FB				
MPress	"Vibrato, Harmonics Level"				
PWheel	(Dist Layer) +2/-12 Pitch Bend				
73	Crunchy Lead			MWheel	Vibrato
		Data	Layer Enable		
		MIDI 22	(KDFX)Dist Drive		
		MIDI 23	(KDFX)Dist Freq		
		MIDI 24	EnvCtl: Dec+Rel		
		MIDI 25	"(Aux) FDR Level, Hall Time"		
		MIDI 26	Flange FB		
		MIDI 27	Flange Tempo		
		MIDI 28	Delay Mix		
		MIDI 29	Delay FB		
		MPress	Layer Balance		
		74	NooMutes^WahTaur	MWheel	Notch and Para EQ Width
				Data	Toggle: Noo Mutes ^ WahTaur
MIDI 22	" Notch Freq (Mutes), BandPass Filt LFO Rate (Wah)"				
MIDI 23	EnvCtl: Imp				
MIDI 24	EnvCtl: Att				
MIDI 25	"(FX1) Hall Wet/Dry, (FX3) Room Mix, (Aux) Room Level"				
MIDI 26	"Delay Mix, Chorus Wet/Dry"				
MIDI 27	"Delay FB, Chorus FB"				
MIDI 28	Delay Time				
MIDI 29	Toggle: FDR + Chorus				
MPress	Vibrato				
AttVel	EnvCtl: Decay				

ID	Name				
75	CeeTaur^Kotolin	MWheel	Vibrato + EQ		
		Data	Toggle: Cee Taur ^ Kotolin		
		MIDI 22	EnvCtl: Imp		
		MIDI 23	EnvCtl: Att		
		MIDI 24	EnvCtl: Rel		
		MIDI 25	"(Aux) Hall Level, (Fx3) Rvb Time"		
		MIDI 26	(Fx2) Phase Wet/Dry		
		MIDI 27	"Phase L/R LFO, (Fx3) Flange Mix"		
		MIDI 28	Delay Mix		
		MIDI 29	"Buss Toggle:, Phaser LFO Rate"		
		MPress	Vibrato		
		76	Liquid T Lead	MWheel	Vibrato
				Data	"EnvCtl: Att, LoPass Freq+Res"
MIDI 22	"Lopass Freq+Res, Steep Bass Freq"				
MIDI 23	EnvCtl: Imp				
MIDI 24	EnvCtl: Rel				
MIDI 25	(Aux) Hall Level				
MIDI 26	"Hall Time+HFDamp, Chorus FB"				
MIDI 27	"Delay Mix, SRS EQ"				
MIDI 28	"Delay FB, SRS Centerspace"				
MIDI 29	Toggle: CHDelay + SRS				
MPress	"Vibrato, Layer Enable (Harmonics)"				
77	Square Lead			MWheel	Vibrato
				Data	"EnvCtl: Att+Dec, LoPass Freq+Res"
		MIDI 22	LoPass Freq+Res		
		MIDI 23	InEQ: Bass		
		MIDI 24	EnvCtl: Rel		
		MIDI 25	(Aux) Hall Level		
		MIDI 26	Hall Decay+HFDamp		
		MIDI 27	"Flange Wet/Dry, DistDrive adj"		
		MIDI 28	"Flange FB+Xcouple+HFDamp, Dist EQ"		
		MIDI 29	Toggle: DistFlange I/O		
		MPress	"Vibrato, Layer Enable (Harmonics)"		
		78	AlaZawi Take 2	MWheel	Vibrato
				Data	LoPass Freq+Res
MIDI 22	LoPass Freq cut				
MIDI 23	InEQ: Bass				
MIDI 24	InEQ: Treb				
MIDI 25	(Aux) Hall Level+Decay Time				
MIDI 26	Hall PreDelay+HFDamp				
MIDI 27	Chorus Wet/Dry+Pan				
MIDI 28	MDelay Wet/Dry				
MIDI 29	Toggle: Clean + MDelayChorus				
Breath	LoPass Freq+Res adj				
MPress	Vibrato				
79	Modulead			MWheel	"Vibrato, Harmonic Balance"
		Data	Filt Freq		
		MIDI 22	LoPass Res adj		
		MIDI 23	EnvCtl: Imp		
		MIDI 24	EnvCtl: Rel		
		MIDI 25	(Aux) Hall Mix		
		MIDI 26	Chorus Mix		
		MIDI 27	Chorus FB		
		MIDI 28	"Phase Center Freq + Notch, Pan Pulse Width"		
		MIDI 29	Toggle: Phaser + Panner		
		MPress	"Slight Vibrato, LoPass adj"		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
80	Polyreal Mini	MWheel	Vibrato
		Data	LoPass Res
		MIDI 22	LoPass Freq
		MIDI 23	"InEQ: Bass, EnvCtl: Att"
		MIDI 24	"InEQ: Treb, EnvCtl: Rel"
		MIDI 25	(Aux) Hall Level+Wet/Dry
		MIDI 26	Hall Decay Time+HFDamp
		MIDI 27	Hall PreDelay
		MIDI 28	Chorus Delay Time+Wet/Dry
		MIDI 29	Delay Mix
		MPress	Vibrato
81	3 Modular Leads	MWheel	Vibrato
		Data	Toggle: Modular Leads
		MIDI 22	"EnvCtl : Imp, HiPass Freq"
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Hall Level, (FX3) Plate Mix"
		MIDI 26	Hall + Plate PreDelay
		MIDI 27	"Flange Wet/Dry, Delay Mix"
		MIDI 28	"Flange FB, Delay FB"
		MIDI 29	Toggle: Flange + CDR
		MPress	Vibrato
82	Soul Boy Lead	MWheel	Vibrato
		Data	Filt Freq+Res
		MIDI 22	InEQ: Bass+Treb
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Decay+HFDamp
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix
		MIDI 29	"Toggle: Delay FB, Chorus adj"
		MPress	Vibrato
83	Fluty Leads	MWheel	Vibrato
		Data	Pitch - Octave Shift
		MIDI 22	InEQ: Bass
		MIDI 23	InEQ: Treb
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Hall Level, (FX3) Hall Mix"
		MIDI 26	(Aux) Hall HFDamp+PreDelay
		MIDI 27	Chorus Mix
		MIDI 28	Chorus Depth
		MIDI 29	Toggle: CDR + Room
		MPress	Vibrato
84	Hrnica^Accordin	MWheel	Vibrato
		Data	Toggle: Hrnica ^ Accordin
		MIDI 22	Layer Switch
		MIDI 23	"InEQ: Bass, Layer Disable, EnvCtl: Rel"
		MIDI 24	InEQ: Treb
		MIDI 25	"(Fx1) Room Wet/Dry, (Aux) Hall Level"
		MIDI 26	"Room Time, Phase FB"
		MIDI 27	"(Aux) Hall adj, Phase Center Freq+LFODepth"
		MIDI 28	(Aux) Hall HFDamp
		MIDI 29	Toggle: Room + Phaser
		MPress	Vibrato

ID	Name		
85	Trmpts^BrBrass	MWheel	(Brass) HiPass Freq
		Data	Toggle: Trumpets ^ Brass
		MIDI 22	"(Brass) Filt Freq, InEQ: Bass"
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Chamber Level
		MIDI 26	Chamber Time+HFDamp
		MIDI 27	InEQ: Treb
		MIDI 28	Chorus FB
		MIDI 29	Chorus I/O
		MPress	Swell
86	Hip Brass	MWheel	Vibrato
		Data	Freq + Res adj
		MIDI 22	InEQ: Treb
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall PreDelay Time, (Fx1) Room Time"
		MIDI 27	"(Fx1) Room Wet/Dry+Time, (Fx2) Sweep Filt Res"
		MIDI 28	(Fx2) Sweep Filt LFO Tempo
		MIDI 29	Sweep Filt I/O
		MPress	Swell
87	Brass De' ROM	MWheel	"Filt Freq, Swell"
		Data	"EnvCtl: Imp, Filt Freq + Res"
		MIDI 22	InEQ: Treb + Bass
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Hall Level, InEQ: Bass boost"
		MIDI 26	Hall Time+HFDamp
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix
		MIDI 29	Hall LP Injection+ PreDelay Time
		MPress	"Vibrato, Swell"
88	BigBand^Hornz	MWheel	"Vibrato, LoPass adj (BigBand)"
		Data	Toggle: BigBand ^ Hornz
		MIDI 22	LoPass Freq Cut (Hornz)
		MIDI 23	"LoPass Res (Hornz), EnvCtl: Att"
		MIDI 24	LoPass ASR (Hornz)
		MIDI 25	(Aux) Room Wet/Dry
		MIDI 26	Room Time
		MIDI 27	Room PreDelay
		MIDI 28	Room HFDamp
		MIDI 29	Enhc I/O
		MPress	Vibrato
89	Z-Plane Brass	MWheel	Vibrato
		Data	EnvCtl: Att +Dec
		MIDI 22	BandPass Filt Freq + Width
		MIDI 23	"InEQ: Bass, EnvCtl: Rel"
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix + Ratio Wet/Dry
		MIDI 29	Delay FB + Hall PreDelay
		MPress	"Vibrato, Slight detune"

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
90	OrcBrs^FrenchBone	MWheel	Vibrato
		Data	Toggle: OrcBrs ^ FrenchBone
		MIDI 22	InEQ: Bass
		MIDI 23	"InEQ: Treb, LoPass Freq"
		MIDI 24	EnvCtl: Imp + Rel
		MIDI 25	(Aux) Hall Mix
		MIDI 26	"Hall Time, Mix adj, Pan Rate(Fx3)"
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix
		MIDI 29	"Hall PreDelay, Pan I/O"
		MPress	"Swell, Vibrato Depth"
91	Brt Saxy Section	MWheel	Vibrato
		Data	"InEQ: Bass, LoPass Freq"
		MIDI 22	InEQ: Treb
		MIDI 23	"EnvCtl: Imp, Att+Dec"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	"Room Wet/Dry + HFDamp, InEQ: Treb Freq"
		MIDI 27	Dist tube Drive
		MIDI 28	Dist Warmth+Tone
		MIDI 29	"Toggle: Dist+EQ I/O, Room type"
		MPress	Vibrato
92	Brt Saxy/Split	MWheel	Vibrato
		Data	InEQ: Bass+Treb
		MIDI 22	EnvCtl: Imp
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	Xfade: (fx1) Chmb + (Aux) Hall
		MIDI 26	Chamb + Hall HFDamp
		MIDI 27	Comp smooth Time
		MIDI 28	Comp signal Delay
		MIDI 29	"Toggle: Chamb + Comp, Hall room size"
		MPress	Vibrato
93	Mr. Parker	MWheel	Vibrato
		Data	LoPass Freq
		MIDI 22	LoPass Res
		MIDI 23	LoPass Freq
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	(Aux) Plate Wet/Dry
		MIDI 26	Plate Time
		MIDI 27	Chorus Mix
		MIDI 28	Delay Mix (sys)
		MIDI 29	"Plate LFO adj, Delay FB"
		MPress	Vibrato
94	Dynasax	MWheel	"Vibrato, LoPass Freq"
		Data	Layer enable
		MIDI 22	"Layer AltCtl, LoPass Freq, Notch Freq, ParaTreb Freq"
		MIDI 23	"Notch Width, LoPass Res, EnvCtl: Imp+Att"
		MIDI 24	EnvCtl: Dec+Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall HFDamp+Decay Time
		MIDI 27	Chorus Mix
		MIDI 28	Delay (sys) Mix
		MIDI 29	Hall PreDelay + room size adj
		MPress	"Vibrato, LoPass Freq+Res, Shape adj"
ChanSt	"Layer AltCtl, EnvCtl: Rel"		

ID	Name		
95	DynTrumpet^Miles	MWheel	"swell, Vibrato"
		Data	Toggle: DynTrumpet ^ Miles
		MIDI 22	LoPass Freq+Res
		MIDI 23	"EnvCtl: Imp, InEQ: Bass"
		MIDI 24	"EnvCtl: Rel, InEQ: Treb"
		MIDI 25	"(fx1) Chamb Wet/Dry, (Aux) Room Level"
		MIDI 26	Chamb + Room Times
		MIDI 27	"Chamb + Room HFDamp, Dist Drive"
		MIDI 28	Dist LoPass Freq
		MIDI 29	Toggle: Chamb + Dist
		MPress	Vibrato
96	Wawa Trumpet (MW)	MWheel	"BandPass Freq, Vibrato, RevRvb HFDamp"
		Data	BandPass Width
		MIDI 22	Bandpass LFO Rate
		MIDI 23	"EnvCtl: Imp, InEQ: Bass"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Wet/Dry+LateTime+Level
		MIDI 26	(fx2) ReverseRvb Wet/Dry
		MIDI 27	ReverseRvb FB
		MIDI 28	"QFlange Wet/Dry, pan"
		MIDI 29	"QFlange I/O, RevRvb adj, Hall cut"
		MPress	Vibrato
97	Almost Muted (MW)	MWheel	"Vibrato, mute adj"
		Data	LoPass Freq
		MIDI 22	HiPass Freq
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(fx1) Room Wet/Dry+Time
		MIDI 26	Room HFDamp
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	EQMorph I/O
		MPress	Vibrato
98	Solo Trombone	MWheel	Vibrato
		Data	LoPass Freq+Res
		MIDI 22	AltControl
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(fx1) Chamb Wet/Dry, (Aux) Room Level"
		MIDI 26	Chmb HFDamp
		MIDI 27	InEQ: Treb
		MIDI 28	Dist Drive adj
		MIDI 29	Toggle: Chmb + Dist
		MPress	Vibrato
99	Jazz Band	MW	Tremolo (guitars)
		Data	Toggle: Guitars + Horns
		MIDI 22	Toggle: Band and Drums
		MIDI 23	Tremolo Rate
		MIDI 25	"(Aux) rvb Levels, Wet/Dry"
		MIDI 26	SRS Parameters (guitar layers)
		MIDI 27	(Aux) rvb Times
		MIDI 28	"Early reflection Level, Late Level cut"

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
100	W.C.Flute^Winds	Data	Toggle: W.C. Flute ^ Winds; BndPass adj
		MIDI 22	"Sax / square Layers enable, Pan position, BndPass adj"
		MIDI 23	adds chiff (sax / square inactive)
		MIDI 24	EnvCtl: Dec (sax / square)
		MIDI 25	(Aux) Hall Level cut
		MIDI 26	Booth Wet/ Dry+HFDamp+Absorption; Echo Level+Balance
		MIDI 27	"Echo Wet/Dry, FB"
		MIDI 28	Echo Tempo
		MIDI 29	Toggle: Booth + Echo
		MPress	Vibrato
101	Baroque Flute	MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	Hall HFDamp
		MIDI 29	"Toggle: Real Room + Perc Room, InEQ: Treb"
102	Synth Caliopies	MW	Vibrato
		Data	Layer disable(up); LoPass Res
		MIDI 22	BandPass Freq; LoPass Freq
		MIDI 23	"LoPass Freq+Res, Hipass Freq, Treb boost"
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	"(Aux) Hall Level, Room Wet/ Dry"
		MIDI 26	Phaser FB
		MIDI 27	Phaser LFO Rate
MIDI 29	"Toggle: Room+Phaser(Layer 1+3), Phaser+CDR(Layer 2+4)"		
103	Incan	MW	Vibrato
		Data	HiPass Freq
		MIDI 22	Panner LFO amt+speed
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Plate cut
		MIDI 26	Chorus Level+FB
		MIDI 27	Delay FB
		MIDI 28	Delay Time (4 increments)
		MIDI 29	"Toggle: Echo I/O (sys), Plate Time, Delay Mix"
MPress	"HiPass Freq LFO amt, Pitch fall"		
104	String Orchestra	Data	Toggle: Layers
		MIDI 22	"LoPass Freq cutoff, Bass boost"
		MIDI 23	EnvCtl: Att
		MIDI 25	(FX1) Hall Wet/Dry+PreDelay
		MIDI 26	Hall Time
		MIDI 27	Hall HFDamp
		MIDI 28	(Layer 2) InEQ: Treb cut
MPress	(Layer 2) volume swell		
105	ClassicalStrings	MW	(Layer 3+4) LoPass separation
		Data	"Toggle: Layers1+2, 3+4"
		MIDI 22	(Layer 1+2) LoPass Freq
		MIDI 23	(Layer 3+4) LoPass Freq+Res cut
		MIDI 24	EnvCtl: Att
		MIDI 25	(FX1) Hall Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall HFDamp
MIDI 28	Hall PreDelay		

ID	Name		
106	StSloStr^SilkStr	MW	Layer balance
		Data	Toggle: StSloStr ^ SilkStr
		MIDI 22	"Layer Delay, LoPass Freq+Res "
		MIDI 23	"EnvCtl: Att, LoPass Freq"
		MIDI 24	"EnvCtl: Att+Dec+Rel, LoPass Freq cut"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	(FX1) Chapel Level
		MIDI 28	Chapel Time
		MPress	"Vibrato, Shaper amt"
107	BigStrgs^FlingStrg	MW	Vibrato ^ Flange Rate
		Data	Toggle: BigStrgs ^ FlingStrg
		MIDI 22	(Layer 1) octave jump
		MIDI 23	EnvCtl: Att
		MIDI 25	(Aux) Hall Level
		MIDI 26	(Aux) Hall Time ^ Phaser CtrFreq
		MIDI 27	Flange FB
		MIDI 28	Flange Rate+L/R phase
		MIDI 29	Toggle: Flange I/O (BigStrgs)
		MPress	"Vibrato, InEQ: Treb"
108	Chamber Ensemble	MW	Chorus Mix
		Data	AllPass Freq
		MIDI 23	EnvCtl: Att
		MIDI 24	InEQ: Bass+Treb
		MIDI 25	"(Aux) Hall Level+PreDelay, (fx1) Hall Mix"
		MIDI 26	Delay Mix+FB
		MIDI 27	Delay Tempo cut
		MIDI 28	(Aux) Hall Time+HFDamp+Injection
		MPress	"Vibrato, AllPass Freq"
		109	Psuedo Violin1^2
Data	"Toggle: Psuedo Violin1 ^ 2, (Vln2) EnvCtl: Att"		
MIDI 22	(Vln1) LoPass Freq cut		
MIDI 23	(Vln2) LoPass Freq cut		
MIDI 24	(Vln1) Shaper Level		
MIDI 25	(Aux) Hall Level		
MIDI 26	Hall LateRvbTime+HFDamp		
MIDI 27	(FX1) Room Wet/Dry		
MPress	Vibrato		
110	Slo Solo Cello		
		Data	LoPass Freq cut+Res cut
		MIDI 22	EnvCtl: Att+Dec
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall LateRvbTime+HFDamp
		MIDI 27	(FX1) Room Wet/Dry
		MIDI 28	Room HFDamp
		MIDI 29	"Toggle: Room type, Hall Wet/ Dry"
		MPress	Vibrato

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
111	Horn&Flute w/Str	MW	"Vibrato, LoPass sep (expression / dynamic ctl)"
		Data	Toggle: Horn ^ Solo String
		MIDI 22	LoPass Freq+Res cut
		MIDI 23	Ens Strings Vol cut
		MIDI 24	Ens Strings EnvCtl: Att
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	(FX1) Chapel Wet/Dry
		MIDI 28	Chapel Time
		MIDI 29	"Toggle: (Layer 3+4) Chapel+Hall, (Layer 1) Hall+Chapel"
		MPress	Ens Strings Vibrato
		SostPd	Toggle: Solo Strg I/O
		112	DynOrch^WTellOrc
Data	Toggle: DynOrch ^ WTellOrch		
MIDI 22	"ParaMid and LoPass Freq, Shaper Drive"		
MIDI 23	"Shaper amt, LoPass Freq"		
MIDI 25	(Aux) Hall Level cut		
MIDI 26	Chapel + Hall Times		
MIDI 29	Toggle: Chapel/Hall + Hall/Room		
MPress	"(DynOrch) Volume swell, shaper amt"		
SostPd	"Layer enable, Room Time"		
113	Touchy Orchestra		
		Data	Hi String cut
		MIDI 22	Lo String ^ Hi Flute
		MIDI 23	Timpani cut
		MIDI 24	Loud Horn ^ Soft Horn
		MIDI 25	"(Aux) Hall Level, Chapel + Rooms Wet/Dry"
		MIDI 26	Chapel Time
		MIDI 29	"Toggle: Chapel+Room, Hall+Chapel"
		MPress	Hi Flute Vibrato Rate
		114	Synth Strings
Data	Toggle: Layer 1 ^ Layer 3		
MIDI 22	Layer 1 up p5th ^ Layer 3 up 8ve		
MIDI 23	EnvCtl: Att		
MIDI 24	EnvCtl: Imp+Rel		
MIDI 25	(Aux) Plate Level		
MIDI 26	"Chorus Wet/Dry, Dist Drive"		
MIDI 27	Chorus FB		
MIDI 28	Dist Bass+Treb tone		
MIDI 29	Toggle: Chorus + Distortion		
MPress	"Vibrato, modulation"		
115	Mellostr^ShineOn	MW	Vibrato
		Data	Toggle: Mellostr ^ ShineOn
		MIDI 22	LoPass+BandPass Freq+Width
		MIDI 23	"EnvCtl: Att, LoPass Res"
		MIDI 24	EnvCtl: Rel
		MIDI 25	"(Aux) Room Level, Hall absorption"
		MIDI 26	"Filt Res, Chorus FB"
		MIDI 27	"Filt Freq, Chorus Rate"
		MIDI 28	"Filt Vibrato, Delay Mix"
		MIDI 29	Toggle: Res Filt + ChorDelay (Mellostr only)
		MPress	"Vibrato, HiPass Freq"

ID	Name				
116	Mellotron (MW)	MW	"3-way toggle: Ens Strg, Solo Strg(dwn 8ve), Flute"		
		Data	Octave jump		
		MIDI 22	LoPass Freq; ParaTreb Freq ; HiFreqStim Freq		
		MIDI 23	"Dist Drv, Xfade dpth; ParaTreb dpth; HFStim Drv"		
		MIDI 25	(Aux) Hall Level		
		MIDI 26	Hall Time		
		MIDI 27	Room Level		
		MIDI 28	Room Time		
		MPress	Vibrato		
		117	RaveStrg^Solina	MW	"Vibrato, Layer detune(Sol)"
				Data	Toggle: RaveStrg ^ Solina
MIDI 22	EnvCtl: Att+Rel				
MIDI 23	"EnvCtl: Dec ^ Ptch mod, Notch LFO Rate"				
MIDI 24	"Flange Mix, Spin Wet/Dry"				
MIDI 25	(Aux) Room Level				
MIDI 26	Spin Pitcher Mix ^ MovDelay Wet/Dry				
MIDI 27	Spin Pitcher Weights				
MIDI 28	Spin Pitcher ptch (rapid echo Rate)				
MIDI 29	"Toggle: Spin I/O, Room HFDamp+Time"				
MPress	Vibrato				
118	Choir Strings	Data	LoPass Freq cut+Res (string)		
		MIDI 22	LoPass Freq cut (vox)		
		MIDI 23	"Layer detune, LoPass Res"		
		MIDI 24	Panner Width		
		MIDI 25	(Aux) Room Level		
		MIDI 26	(Aux) Room Time		
		MIDI 27	Flange Level		
		MIDI 28	Flange Tempo		
		MIDI 29	"Toggle: Room + Flange (string), ChHall + Hall (vox)"		
		119	CathdrVox^8veVox	MW	"Vibrato+Rate (CathV), Sin Tremolo Rate (8veV)"
Data	Toggle: CathedralVox ^ 8veVox				
MIDI 22	"EnvCtl: Att, LoPass Freq, Xfade Lo/Hi Vox(8veV)"				
MIDI 23	"EnvCtl: Rel, Panner pos, 8ve jump(CathV)"				
MIDI 24	InEQ: Treb cut				
MIDI 25	(Aux) Hall Level				
MIDI 26	(Aux) Hall Time+build Time				
MIDI 27	Delay Mix+FB				
MIDI 28	Flange Mix+FB				
MPress	"Vibrato+Rate (CathV), Sin Tremolo Rate (8veV)"				
120	Mixed Choir			MW	Vibrato+Rate
		Data	Layer XFade		
		MIDI 22	"EnvCtl: Rel, Notch + ParaTreb Freq"		
		MIDI 23	"InEQ: Bass, ParaTreb, Notch Width"		
		MIDI 24	InEQ: Treb		
		MIDI 25	(Aux) Hall Level		
		MIDI 26	Room Wet/Dry		
		MIDI 27	Room Time		
		MIDI 28	Infinite Decay on Keydown		
		MIDI 29	Infinite Decay		
		MPress	Vibrato+Rate		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
121	NUChoir^SpaceVox	MW	Vibrato
		Data	Toggle: NUChoir ^ SpaceVox
		MIDI 22	"EnvCtl: Att, Shaper amt ^ LoPass Freq"
		MIDI 23	EnvCtl: Rel
		MIDI 24	LoPass Freq (SpaceVox)
		MIDI 25	(Aux) Hall: Level+buildTime+DecayTime+PreDelay+HFDamp
		MIDI 26	(Aux) Hall Bass gain
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	Toggle: (Aux) Hall I/O (SpaceVox)
		MPress	Vibrato
		122	Marimbae^Vibeish
Data	Toggle: Marimbae ^ Vibish		
MIDI 22	"Xfde: Layer 1+2, Layer detune, LP / HPass freq, HFStim Drive"		
MIDI 23	"Layer 2 alt Toggle, EnvCtl: Rel"		
MIDI 24	EnvCtl: Imp+Dec		
MIDI 25	"(Aux) Hall Level, Room Wet/Dry"		
MIDI 26	Hall+Room Times		
MIDI 29	Toggle: Room + Compressor/ Hall ^ Room I/O		
123	SlidersIn Africa	MW	"Layer 2 Xfade, Panner Pos"
		Data	LoPass Freq cut
		MIDI 22	HiPass Freq
		MIDI 23	Panner LFO amt+Pos
		MIDI 24	Pitch drop
		MIDI 25	Delay Time
		MIDI 26	Delay FB
		MIDI 27	Laser Contour
		MIDI 28	Laser Spacing
		MIDI 29	(Aux) Room Time adj
124	MalletFlts Split	MW	Pitch up (Layer1+6)
		Data	Layer5 Enable
		MIDI 22	"LoPass Freq+Res, Shape mod (Layer 4), ParaTreb boost"
		MIDI 23	"HiPass Freq (Layer3), Shaper amt, Notch Freq (Layer 4), Panner Pos(Layer 3)"
		MIDI 25	(Aux) Space Rvb Level+Mix+Time
		MIDI 26	Delay Mix
		MIDI 27	Delay Time
		MIDI 29	"Toggle: CDR + Chorus, (Layers 1, 2, 6)"
		MPress	Notch Freq
125	Malletoo	MW	"Pitch modulation, Vibrato"
		Data	"Pitch mod LFO speed, LoPass Freq (Layer 3)"
		MIDI 22	LoPass Res cut (Layer 3)
		MIDI 23	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level+Time+HFDamp
		MIDI 26	(Aux) Delay Mix cut
		MIDI 27	Flange Wet/Dry
		MIDI 28	Flange FB
		MIDI 29	Toggle: Flange I/O
		MPress	Vibrato

ID	Name		
126	Highlandistic	MW	(Aux) Hall Infinite Decay Vibrato
		Data	EnvCtl: Rel
		MIDI 22	ParaTreb Freq
		MIDI 23	"InEQ: Bass, Notch+HiPass Freq"
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall Time+HFDamp, Chorus Mix"
		MIDI 27	Delay Mix+FB
		MIDI 28	Chorus Level cut
		MIDI 29	Toggle: Infinite Decay I/O
		MPress	Vibrato
		127	Buzz Kill
Data	LoPass Freq		
MIDI 22	"LoPass Res cut, Dist Drive cut"		
MIDI 23	"EnvCtl: Att, Flange LFO"		
MIDI 24	"EnvCtl: Rel, Flange L/R phase"		
MIDI 25	Flange Delay Tempo		
MIDI 26	Flange FB		
MIDI 27	(Aux) CDR Level cut		
MIDI 28	(Aux) Delay Mix		
MIDI 29	(Aux) Hall Wet/Dry+Time adj		
MPress	LoPass Freq		
128	Harshey's	MW	Pitch modulation
		Data	LoPass Freq
		MIDI 22	"LoPass Res cut, Dist Drive cut"
		MIDI 23	"EnvCtl: Att, Flange LFO"
		MIDI 24	"EnvCtl: Rel, Flange L/R phase"
		MIDI 25	"Flange Wet/Dry, (Aux) Delay Tempo"
		MIDI 26	Flange FB
		MIDI 27	(Aux) CDR Level
		MIDI 28	(Aux) Delay Mix
		MIDI 29	(Aux) Hall Wet/Dry+Time adj
MPress	LoPass Freq		
129	Spunter	MW	Pitch octave jump
		Data	"EnvCtl: Dec, Rel"
		MIDI 22	Pitch octave+jump
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level+Mix
		MIDI 26	Hall Time
		MIDI 27	(Aux) Delay Mix+Dry Balance
		MIDI 28	Distortion Wet/Dry+Warmth+HiPass
130	Crumper	MW	Vibrato
		Data	EnvCtl: Att+Rel
		MIDI 22	DSP Xfade: SW+SHP
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Mix+Time+PreDelay
		MIDI 26	(Aux) Delay Mix
		MIDI 27	Dist Drive
		MIDI 28	Dist Warmth
		MIDI 29	Toggle: Delay I/O
MPress	Vibrato		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
131	Zeek	MW	Pitch modulation
		Data	LoPass Freq cutoff
		MIDI 22	"LoPass env amt, 8ve jump"
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(FX2) Room Wet/Dry cut
		MIDI 26	Room Time
		MIDI 27	Dist Wet/Dry
		MIDI 28	(Aux) GrphEQ I/O
		MIDI 29	Toggle: AClock Amp modulation I/O
132	Elephantiasis	MW	HiPass Freq
		Data	HiPass Freq
		MIDI 22	Pitch
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) EQ 1k Level
		MIDI 26	(Aux) EQ 2k Level
		MIDI 27	(Aux) EQ 4k Level
		MIDI 28	(Aux) EQ 8k Level
		MIDI 29	(Aux) Level cut
133	SoftMatrix12 5th	MW	Vibrato
		Data	"LoPass Freq, EnvCtl: Att+Dec"
		MIDI 22	Pitch drop
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Plate Level
		MIDI 26	Plate HFDamp+Decay Time
		MIDI 27	Echo Wet/Dry
		MIDI 28	Echo FB
		MIDI 29	"Toggle: Echo I/O, Plate room size adj"
GAttVel	Echo HFDamp		
MPress	Vibrato		
134	TchRezoid^Hungry	MW	"Vibrato, Phaser Ctr Freq"
		Data	Toggle: TchRezoid (EnvCtl: Att+Dec) ^ Hungry (EnvCtl: Rel)
		MIDI 22	"HiPass Res, Wrap amt ^ LoPass Res, "
			"Saw+Shp 8ve jump, Xfade: triangle+saw"
		MIDI 23	HiPass sep ^ EnvCtl: Att
		MIDI 24	EnvCtl: Rel ^ EnvCtl: Imp
		MIDI 25	AstralTaps Wet/Dry+FB
		MIDI 26	(Aux) Phaser Level
		MIDI 27	"Phaser Notch, BandPass adj"
		MIDI 28	AstralTaps Tempo
MPress	Vibrato		
135	Matchstik^NUDigi	MW	"Vibrato, Phaser Ctr Freq"
		Data	Toggle: MatchStik ^ NUDigi
		MIDI 24	(Aux) Phaser Level+FB cut
		MIDI 25	(Aux) Phaser Notch/ BP
		MIDI 26	AstralTaps Wet/Dry+FB
		MIDI 27	AstralTaps FB image
		MIDI 28	AstralTaps Tempo
		MPress	Vibrato

ID	Name		
136	Peppers Digiclub	MW	"Pitch chng+mod, LFO Depth(VAST+(Aux) Hall)"
		Data	LoPass Freq
		MIDI 22	"Pitch jump, Pitch LFO Rate Toggle"
		MIDI 23	EnvCtl: Att
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level (MIDI 29 out)
		MIDI 26	(Aux) Hall Time
		MIDI 27	Flange Wet/Dry
		MIDI 28	Flange Feedback
		MIDI 29	"(Aux) Hall Level+Mix+LFO Depth+Rate, Flange Dry cut"
MPress	Pitch changes		
137	Frog^LowNoteTalk	MW	Vibrato
		Data	Xfade: Frog ^ LowNoteTalk
		MIDI 22	"Pitch Drop, Wrap amt"
		MIDI 23	ShpOsc Depth ^ Wrap amt
		MIDI 24	BandPass+AllPass Freq
		MIDI 25	"EQ Morph ""A"" Freq scale"
		MIDI 26	"EQ Morph ""B"" Freq scale"
		MIDI 27	Echo Wet/Dry
		MIDI 28	Echo FB
		MIDI 29	Toggle: EQ Morph + Echo
MPress	Vibrato		
138	Oink Doink	MW	Vibrato
		Data	EnvCtl: Att+Dec
		MIDI 22	HiPass Res cut
		MIDI 23	"InEQ: Bass, HiPass separation"
		MIDI 24	"InEQ: Treb, EnvCtl: Imp"
		MIDI 25	(Aux) Hall Level
		MIDI 26	(Aux) Delay Level
		MIDI 27	Laser spacing
		MIDI 28	Laser Contour
		MIDI 29	Toggle: Laser I/O
MPress	Vibrato		
LgeRbn	Laser Delay Coarse		
139	Wheepy Dood	MW	Vibrato
		Data	LoPass Freq
		MIDI 23	EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	Chorus Mix+Delay
		MIDI 26	Chorus Depth+Rate
		MIDI 27	Chorus FB
		MIDI 28	Delay Mix+FB
		MPress	Vibrato
		140	Funk O Matic
Data	LoPass Freq		
MIDI 22	"Shaper amt, LoPass Freq cut"		
MIDI 23	Dist Drive		
MIDI 24	(Layer 1+3) 8ve drop		
MIDI 25	Env Filt thReshold		
MIDI 26	Env Filt min Freq		
MIDI 27	(Aux) Sweep Filt Wet/Dry		
MIDI 28	(Aux) Sweep Filt min Freq		
MIDI 29	Toggle: Env Filt - BandPass and HiPass		
MPress	"Vibrato, Layer detune"		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
141	Pulsemonster5ths	MW	Vibrato
		Data	"PWM Width, LoPass Freq, Dist Drv cut"
			EnvCtl: Att+Dec+Rel
		MIDI 22	Dist Drv cut
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	"(Aux) Hall PreDelay, Decay Time, HFDamp, Bass gain"
		MIDI 27	Chorus Depth
		MIDI 28	Delay Mix+FB
		MPress	Vibrato
142	OB Pad^OB Brass	MW	Vibrato
		Data	Toggle: OBPAd ^ OB Brass
		MIDI 22	"LoPass Freq, EnvCtl: Att+Rel (pad)"
		MIDI 23	LoPass Res ^ LoPass Freq
		MIDI 24	EnvCtl: Imp (brass)
		MIDI 25	(Aux) Plate Level+Time
		MIDI 26	"Enhc Lo Drive+Mix, Chorus Wet/Dry "
		MIDI 27	"Enhc Mid Drive, Mid Mix"
		MIDI 28	"Enhc Hi Drive, Hi Mix, InEQ: Treb"
		MIDI 29	Toggle: Enhancer + Chorus
		MPress	Vibrato
143	Detooner^BigPMW	MW	Vibrato
		Data	Toggle: Detooner ^ BigPMW
		MIDI 22	"P5th jump ^ LoPass Freq, EnvCtl: Att+Rel"
		MIDI 23	"Notch Freq ^ Dist drv, EnvCtl: Imp"
		MIDI 24	"PWM Width, Dist drv"
		MIDI 25	(Aux) Laser Level
		MIDI 26	(Aux) Laser contour+FB
		MIDI 27	"Flange FB+L/R phase, Phaser Ctr Freq"
		MIDI 28	"Flange Wet/Dry cut, Phaser Wet/Dry"
		MIDI 29	Toggle: Flange + Phaser
		MPress	Vibrato
144	TeknoBallCrusher	MW	Vibrato
		Data	"EnvCtl: Att, Notch Freq"
		MIDI 22	saw 8ve jump (Layer 1)
		MIDI 23	EnvCtl: Impact
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	Chorus Wet/Dry; Dist Drive cut
		MIDI 27	Chorus Rate; Dist warmth cut
		MIDI 28	Chorus FB; Dist cab LoPass
		MIDI 29	Toggle: Chorus + Distortion
		MPress	Vibrato
145	VTrig SquareHead	MW	Vibrato
		Data	BandPass Freq Env amt+Width
		MIDI 23	"EnvCtl: Imp, Saw Pitch, InEQ: Bass "
		MIDI 24	"EnvCtl: Rel, InEQ: Treb"
		MIDI 25	(Aux) Delay Mix
		MIDI 26	(Aux) Chorus Mix
		MIDI 27	Phaser FB cut
		MIDI 28	Phaser Ctr Freq
		MIDI 29	(Aux) Chorus Delay cut
		MPress	Vibrato

ID	Name		
146	Razor Saw	MW	Vibrato
		Data	"LoPass LFO Rate, Shaper amt, EnvCtl: Att+Dec "
		MIDI 22	EnvCtl: Rel
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level+PreDelay+Time+HFDamp
		MIDI 26	Delay FB+Mix
		MIDI 27	Chorus Depth+Rate
		MIDI 28	Chorus FB
		MIDI 29	Toggle: Delay I/O
		MPress	Vibrato
147	Razorip Buzzsaw	MW	Vibrato
		Data	"EnvCtl: Rel, HiPass Freq"
		MIDI 22	Sine Pitch
		MIDI 23	Saw+Sine Pitch
		MIDI 24	InEQ: Bass+Treb
		MIDI 25	(Aux) Hall Time+HFDamp
		MIDI 26	(Aux) Delay Mix
		MIDI 27	Phaser FB cut
		MIDI 28	Phaser Ctr Freq+LFO Rate
		MIDI 29	(Aux) Chorus Delay adj
		MPress	"Vibrato, Phaser LFO Rate"
148	Pulse Pass	MW	Vibrato
		Data	HiPass Freq
		MIDI 22	PWM Width
		MIDI 23	EnvCtl: Imp
		MIDI 24	"EnvCtl: Att+Rel, Dist drv cut"
		MIDI 25	"(Aux) Hall Level+Time, Delay HFDamp"
		MIDI 26	Delay Mix
		MIDI 27	Chorus Rate+Depth
		MIDI 28	Chorus FB
		MIDI 29	(Aux) Hall PreDelay adj
		MPress	Vibrato
149	Nordic Square	MW	Vibrato
		Data	Lo+Hi Pass Freq cut
		MIDI 22	EnvCtl: Att
		MIDI 23	EnvCtl: Imp
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level; Flange/ Dry>Delay Mix
		MIDI 26	"Chorus Mix, Depth+Delay"
		MIDI 27	Chorus Rate+FB
		MIDI 28	Delay Mix+FB
		MIDI 29	Toggle: ChorusDelay/(Aux) Hall + Flange/Delay
		MPress	Vibrato
150	Rezonant Snob	MW	Vibrato
		Data	Filt LFO
		MIDI 22	Filt Res
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Wet/Dry
		MIDI 26	Hall Time
		MIDI 27	Hall preDelay+HFDamp
		MIDI 28	Delay Mix
		MIDI 29	Toggle: Delay Time cut+HFDamp adj
		MPress	"Vibrato, Filt Freq"

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
151	Borfin'Jumps^RPT	MW	"EnvCtl: Att+Dec, Rel"
		Data	Toggle: Borfin'Jumps ^ RPT
		MIDI 22	Pitch jump
		MIDI 23	"LoPass Res, "
		MIDI 24	"KDFX InEQ: Treb, Env Ctl (Impact), Amp modulation"
		MIDI 25	"(Aux) rvb Level + Time, PreDelay Time"
		MIDI 26	"Delay Mix, Chorus Delay Time"
		MIDI 27	Phaser FB
		MIDI 28	Phaser LFO Rate
		MIDI 29	Phaser Notch/BandPass balance
		MPress	Phaser LFO Rate
152	Elektro Funk	MW	Modulation
		Data	"Synch slave de-tune, Notch Freq"
		MIDI 22	Synch Master de-tune
		MIDI 23	EnvCtl Att
		MIDI 24	EnvCtl Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	"Hall Time, size"
		MIDI 27	Vibrato Phaser Wet/Dry
		MIDI 28	"Vibrato Phaser Width, InEQ: Treb"
		MIDI 29	Toggle: Echo on
		MPress	
153	Acid	MW	Pitch up
		Data	HiPass Freq
		MIDI 22	LoPass Res Freq
		MIDI 23	LoPass Res env
		MIDI 24	EnvCtl: Rel
		MIDI 25	Shaper Mid amount
		MIDI 26	Delay Level
		MIDI 27	Delay FB
		MIDI 28	Delay Time
MIDI 29	Toggle: (Aux) Hall Level boost		
154	Rancid	MW	Pitch adj
		Data	HiPass Freq
		MIDI 22	LoPass Res Freq
		MIDI 23	LoPass Res env amt
		MIDI 24	EnvCtl: Rel
		MIDI 25	Shaper Mid amount
		MIDI 26	Echo Level
		MIDI 27	Echo FB
		MIDI 28	Echo Time
MIDI 29	Toggle: (Aux) Hall Level boost		
155	Fuse	MW	System-Synched modulation
		Data	LoPass Freq
		MIDI 22	Lo pass Res cut
		MIDI 23	Pitch drop ASR
		MIDI 24	EnvCtl: Rel
		MIDI 25	Env Filt amt
		MIDI 26	Env Filt min Freq
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	Toggle: Sweep Filt I/O
		MPress	Gain boost

ID	Name		
156	Squwee Monosync	MW	Vibrato
		Data	Layer enable
		MIDI 22	EnvCtl: Att
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Booth Level
		MIDI 26	"Gated rvb Wet/Dry cut, Flange Level cut"
		MIDI 27	"Gated rvb size scale, Echo Level"
		MIDI 28	"Echo HFDamp, Echo Level + FB"
		MIDI 29	Toggle: Gated rvb + FlangeEcho
		MPress	Vibrato
157	Generic Ravelead	MW	Pitch mod
		Data	"LoPass Freq cut, EnvCtl: Att+Dec"
		MIDI 22	"LoPass Res, HiPass Freq"
		MIDI 23	LoPass Res cut
		MIDI 24	"Samp alt start, EnvCtl: Imp"
		MIDI 25	(Aux) Booth Level
		MIDI 26	"Echo Wet/Dry, LFO Filt pulse Width"
		MIDI 27	"Echo FB, LFO Filt smooth"
		MIDI 28	"Echo HFDamp, LFO Filt Res"
		MIDI 29	Toggle: Echo + LFO Filt
		MPress	Vibrato
158	Notch Sinker	MW	Vibrato
		Data	EnvCtl: Att+Dec
		MIDI 22	SyncM Pitch adj
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Booth Level
		MIDI 26	"Shaper Wet/Dry cut, Reverse rvb Wet/Dry"
		MIDI 27	"Shaper amount, Reverse rvb envelope"
		MIDI 28	"Reverse rvb length, Delay length"
		MIDI 29	"Toggle: shaper + reverse rvb, (Aux) Booth type+Time"
		MPress	Vibrato
159	Grungesync Sweep	MW	Vibrato
		Data	EnvCtl: Att+Dec
		MIDI 22	Layer LoPass Freq cut
		MIDI 23	Saw wave Pitch jump
		MIDI 24	EnvCtl: Imp
		MIDI 25	(Aux) Hall Level
		MIDI 26	Flange Level
		MIDI 27	"Shaper Level, Quantize Wet/Dry"
		MIDI 28	Shaper amount
		MIDI 29	"Toggle: ShaperFlange + QuantizeFlange, (Aux) Hall Time"
		MPress	Vibrato

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
160	Rezzysaws	MW	Vibrato
		Data	LoPass Freq
		MIDI 22	EnvCtl: Att
		MIDI 23	Saw wave Pitch adj
		MIDI 24	EnvCtl: Imp
		MIDI 25	"(Aux) Hall Level, Wet/Dry"
		MIDI 26	"EnvFilt thReshold, Chorus Level"
		MIDI 27	"EnvFilt sweep, Delay Level"
		MIDI 28	"EnvFilt min Freq, Delay Time"
		MIDI 29	Toggle: EnvFilt + ChorDelay
		MPress	Vibrato
161	Prophet Sync	MW	"Pitch adj, Vibrato"
		Data	"LoPass Freq + Res, Sync slave Pitch, Layer EnvCtl: Rel"
		MIDI 22	Layer Pitch adj
		MIDI 23	InEQ: Treb
		MIDI 24	EnvCtl: Att + Imp
		MIDI 25	(Aux) rvb Level + HFDamp
		MIDI 26	"FX2 Flange Level, FX3 Flange Wet/Dry"
		MIDI 27	"Shaper Level, Quantize Wet/Dry"
		MIDI 28	Shaper amount
		MIDI 29	Toggle: FlangeShaper + QuantizeFlange
		MPress	Pitch mod
162	Glider	MW	"LoPass LFO Rate, Vibrato"
		Data	LoPass Freq LFO amt
		MIDI 22	LoPass Res
		MIDI 23	Notch Freq
		MIDI 24	"Flange FB, EnvCtl: Imp"
		MIDI 25	(Aux) LaserDelay Level
		MIDI 26	"Flange Wet/Dry, Phaser Wet/Dry"
		MIDI 27	LaserDelay Time
		MIDI 28	LaserDelay FB
		MIDI 29	"Toggle: Flange + Phaser, LaserDelay adj"
		MPress	Vibrato
163	AlaskaGlide (MW)	MW	Toggle: Alaska + Glide
		Data	EnvCtl: Imp
		MIDI 22	EnvCtl: Att
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Levels
		MIDI 26	FDR Wet/Dry
		MIDI 27	InEQ: Bass
		MIDI 28	InEQ: Treb
		MIDI 29	FlgDelayrvb I/O
		MPress	"Vibrato, Layer detune, LoPass Freq, Flange XCurs + FB"
164	RaveClassic^Braz	MW	Vibrato
		Data	Toggle: RaveClassic + Braz
		MIDI 22	"EnvCtl: Imp ^ NotchFilt Freq, EnvCtl: Imp"
		MIDI 23	EnvCtl: Dec ^ EnvCtl: Att+Dec
		MIDI 24	EnvCtl: Rel ^ EnvCtl: Rel
		MIDI 25	"Hall Mix + Time, Delay Mix"
		MIDI 26	Panner LFO Rate
		MIDI 27	Pan image Width
		MIDI 28	Delay Tempo
		MIDI 29	Echo I/O
		MPress	Vibrato

ID	Name		
165	Meditator^SloEns	MW	"Vibrato, LoPass Res"
		Data	Toggle: Meditator + SloEns
		MIDI 22	"LoPass Freq + Res, HFstim adj, Layer Pitch adj"
		MIDI 23	"BandPass Freq, Layer Pitch adj (SloEns)"
		MIDI 24	"Layer Shape adj, EnvCtl: Imp"
		MIDI 25	(Aux) Hall Level + Decay Time ^ Minivrb Level
		MIDI 26	Flang Wet/Dry ^ Minivrb Time + PreDelay
		MIDI 27	Flange FB
		MIDI 28	Delay FB
		MIDI 29	Toggle: Flange + CDR
		MPress	Vibrato
AttVel	EnvCtl: Rel		
MIDI 70	"AltCtl, EnvCtl: Imp"		
166	Tranquil Picked	MW	"Vibrato, Notch Freq env amt"
		Data	"Layer LoPass Freq + Xfade, AllPass Freq, Notch Width, EnvCtl: Rel"
		MIDI 22	"Layer HiPass Freq, Pan adj, AllPass Freq"
		MIDI 23	"Layer Pitch adj, AllPass adj"
		MIDI 24	"Layer Pitch env, EnvCtl: Att"
		MIDI 25	(Aux) Echo Level
		MIDI 26	Flange Wet/Dry
		MIDI 27	Laser coarse Delay
		MIDI 28	Laser contour
		MIDI 29	Toggle: Flange + LaserVrb
		MPress	Vibrato
167	The Chaser	MWheel	Vibrato
		Data	"LoPass Freq, EnvCtl: Att+Dec+Rel"
		MIDI 22	LoPass Freq+Res
		MIDI 23	"HFstim adj, Dist Drive"
		MIDI 24	PWM Width
		MIDI 25	"Rooms Wet/Dry (FX1,FX2)"
		MIDI 26	Rooms HFDamp+Time
		MIDI 27	(Aux) Hall Level
		MIDI 28	Hall HFDamp
		MIDI 29	Toggle: Rooms
		AttVel	AltCtl
KeyNum	"HFstim LFO, BandPass Width, Notch Freq"		
MPress	Vibrato		
168	Enterprize^MTree	MWheel	"Vibrato, Tremolo"
		Data	Toggle: Enterprize ^ MTree
		MIDI 22	"Pitch jump, HFStim ^ EnvCtl: Att+Dec"
		MIDI 23	"HiPass Freq, Dist Drive (VAST)"
		MIDI 24	"DSP XFade, Pitch adj, EnvCtl: Rel"
		MIDI 25	(Aux) Acid Room Level
		MIDI 26	"Acid dry Level cut, Dist Drive adj ^ LasrVrb Wet/Dry"
		MIDI 27	Dist warmth ^ LasrVrb Delay Time
		MIDI 28	Dist Freq adj ^ LasrVrb contour
		MIDI 29	Distortion I/O
		MPress	"Vibrato, Tremolo"
AttVel	EnvCtl: Rel		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
169	Orgazmica	MWheel	Layer detune
		Data	LoPass Freq cut
		MIDI 22	Pitch octave adj
		MIDI 23	"EnvCtl: Att, HiPass Freq"
		MIDI 24	"EnvCtl: Rel, LoPass Res"
		MIDI 25	"(Aux) Booth Level, (FX1) Room Wet/Dry"
		MIDI 26	Hall HFDamp+Absorption+Time
		MIDI 27	Tremolos
		MIDI 28	Flange FB + Wet/Dry
		MIDI 29	Toggle: (FX1) Room I/O
170	Universal	MWheel	Vibrato
		Data	Pitch adj
		MIDI 22	Amp gain
		MIDI 23	Pitch adj
		MIDI 24	"Saw detune, Pan adj, Square Level"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Flange FB
		MIDI 27	Flange LFO Tempo
		MIDI 28	Flange Xcouple
		MIDI 29	"Toggle: Room + Flange, Hall Decay Time"
MPress	Layer Vibrato + boost		
171	Asian Digital	MWheel	"Vibrato, Shaper Level"
		Data	EnvCtl: Att+Dec
		MIDI 22	SW+SHP Pitch+pan+Level
		MIDI 23	EnvCtl: Imp+Dec
		MIDI 24	(Aux) Delay FB
		MIDI 25	(Aux) Hall Mix+Time
		MIDI 26	(Aux) Chorus FB
		MIDI 27	Flange Wet/Dry
		MIDI 28	Flange FB+phase
		MIDI 29	Toggle: Flange I/O
MPress	"Vibrato, Shaper Level"		
KeyNum	Pos bal LFO		
172	Wheel Wave Sweep	MWheel	"Layer Xfade, vib, Pan LFO, BandPass Width"
		Data	"BandPass Freq+Width, LoPass + HiPass adj"
		MIDI 22	"LoPass Res, HiPass Res, Pan adj"
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time+HFDamp
		MIDI 27	Flange FB Level
		MIDI 28	Flange LFO Tempo
		MIDI 29	Toggle: Flange I/O
MPress	Vibrato		
173	Arystal^InTheAir	MWheel	Vibrato
		Data	Toggle: Arystal ^ InTheAir
		MIDI 22	Layer Pitch adj ^ LoPass adj
		MIDI 23	"LoPass Freq ^ Saw Pitch, Layer detune"
		MIDI 24	"Layer Pitch adj, Layer Xfade"
		MIDI 25	(Aux) Hall Level+Time
		MIDI 26	Chorus Wet/Dry
		MIDI 27	Chorus FB
		MIDI 28	Chorus Rate
		MIDI 29	"ChorusDelay I/O (sys), InEQ: Treb boost"
MPress	Vibrato		
ControlD	Amp cut		

ID	Name		
174	Cymbal Singers	MWheel	Vibrato
		Data	Layer 3 volume (ride cymbal)
		MIDI 22	"BandPass Width, HiPass Res"
		MIDI 23	Pan LFO adj
		MIDI 24	InEQ: Treb cut
		MIDI 25	(Aux) LaserVrb Level
		MIDI 26	LaserVrb contour
		MIDI 27	Pitch LFO Rate
		MIDI 28	Flange FB
		MIDI 29	Toggle: Pitcher + PitcherFlange
MPress	"Vibrato, BandPass Freq"		
KeyNum	EnvCtl: Att+Dec		
GKeyNum	Pitcher Pitch+Weights		
PWheel	BandPass Freq		
175	BriteBells^Glock	MWheel	Vibrato
		Data	Layer Toggle: BriteBells + Glock
		MIDI 22	Layer Levels ^ EnvCtl: Att
		MIDI 23	"Pitch adj, EnvCtl: Dec"
		MIDI 24	InEQ: Bass ^ EnvCtl: Imp
		MIDI 25	"(Aux) Room Level, (FX1) Hall Wet/Dry cut"
		MIDI 26	Room Decay Time
		MIDI 27	"Chorus Wet/Dry, Echo Wet/Dry"
		MIDI 28	"Chorus FB, Echo FB"
		MIDI 29	"Toggle: Chorus in/out, Hall + Echo out"
MPress	Vibrato		
176	Crystaline^RX7	MWheel	"Shaper ctl, Vibrato ^ Pan adj"
		Data	Toggle: Crystaline ^ RX7
		MIDI 22	"ShapeMod osc Pitch, Shape amt ^ LoPass Freq, Pitch adj"
		MIDI 23	"LoPass Res, EnvCtl: Att"
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Room Level
		MIDI 26	Room Decay Time+HFDamp
		MIDI 27	"Chorus Wet/Dry, Echo Wet/Dry"
		MIDI 28	"Chorus FB, Echo FB"
		MIDI 29	Toggle: Chorus + Echo
MIDI 70	Layer AltCtl		
177	Wave Power 2	MWheel	"Vibrato, In Pan adj"
		Data	"Layer enable, EnvCtl: Dec+Rel"
		MIDI 22	"Hall Wet/Dry, Layer Delay"
		MIDI 23	Hall Time
		MIDI 24	LaserVrb contour
		MIDI 25	"InEQ: Bass, Laser spacing"
		MIDI 26	"InEQ: Treb, Laser envelope"
		MIDI 27	Laser Level+FB+Pitch
		MIDI 28	LaserDelay Time
		MIDI 29	Pitcher Level
MPress	Vibrato Layer		
178	Trinibell	MWheel	Pitch ASR ctl
		Data	Hi+LoPass Freq
		MIDI 22	"Hi+LoPass Freq+Res, Pitch LFO"
		MIDI 23	"Enc Ctl - Att, Dist Drive adj"
		MIDI 24	EnvCtl: Rel
		MIDI 25	Tremolo Depth
		MIDI 26	Flange Wet/Dry
		MIDI 27	Chorus Mix
		MIDI 28	Delay FB (sys)
		MIDI 29	Flange FB boost
MPress	"Dist Drive, Hi+LoPass Freq"		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
179	Frozen^ Pizzibell	MWheel	Tremolo
		Data	Toggle: Frozen ^ Pizzibell
		MIDI 22	Hi+LoPass Freq ^ EnvCtl: Imp
		MIDI 23	"LoPass Res, Env Ctl - Att"
		MIDI 24	"LoPass Freq+Res, HiPass Freq ^ EnvCtl: Rel"
		MIDI 25	Delay Mix (sys)
		MIDI 26	Delay Time
		MIDI 27	Chorus Mix
		MIDI 28	"(Aux) Wet/Dry cut, InEQ: Bass"
		MIDI 29	Toggle: Flange I/O
180	Dency	MWheel	Pitch LFO adj
		Data	"LoPass Freq, ChorDelay Wet/Dry"
		MIDI 22	LoPass LFO
		MIDI 23	"Pan ctl, EnvCtl: Att"
		MIDI 24	"Pitch ctl, EnvCtl: Rel"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	Delay Time (sys)
		MIDI 28	Delay Mix + FB
		MIDI 29	"Toggle: Chorus I/O, Delay Level"
181	Synth Bell 1^2	MWheel	"Vibrato, Pan adj, LoPass Res"
		Data	"Toggle: Synth Bells 1 + 2, AltCtl adj"
		MIDI 22	"LoPass Res, BandPass Width, EnvCtl: Rel"
		MIDI 23	Pan adj
		MIDI 24	Pitch LFO adj
		MIDI 25	"(Aux) Hall Level, (fx1) Chapel Wet/Dry"
		MIDI 26	"Hall HFDamp+Time, Chapel Time"
		MIDI 27	"Chapel preDelay, SRS center Freq adj"
		MIDI 28	"Chapel EarlyRef+Late Levels, SRS EQ adj"
		MIDI 29	Toggle: Chapel + SRS
182	DynPercMix^Gator	BKeyNu	EnvCtl: Att+Dec+Rel
		MPress	Vibrato
		MWheel	"LoPass Freq+Res, Layer EnvCtl: Rel+Att"
		Data	Toggle: DynPercMix + Gator
		MIDI 22	"Filt Freq+Res+Width, Pitch, EQ, EnvCtl: Att ^ Lo+AllPass Freq"
		MIDI 23	"LoPass Freq, Pitch adj ^ ParaMid+Treb Freq"
		MIDI 24	"BandPass Width, Layer Level + Xfade"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall HFDamp + Decay Time
		MIDI 27	"Flange Wet/Dry, MDelay Wet/Dry"
MIDI 28	"Flange FB, MDelay FB"		
MIDI 29	Toggle: Flange + TubeAmpDelayChorus		
ChanS	EnvCtl: Rel		
AttVel	EnvCtl: Dec		

ID	Name		
183	Workingman Space	MWheel	slight Vibrato
		Data	"LoPass Freq, Pitch adj"
		MIDI 22	"HiPass Freq, HFstim, BandPass Width"
		MIDI 23	Pipe Pitch bend
		MIDI 24	Pipe Pitch adj
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time
		MIDI 27	Hall HFDamp
		MIDI 28	Hall Wet/Dry cut
		MIDI 29	Toggle: ChorusVrb + St Image
184	OronicoKno^Shift	MPress	slight Vibrato
		MWheel	Vibrato
		Data	Toggle: OronicoKno + Shift
		MIDI 22	"HFstim adj, Pan adj"
		MIDI 23	"InEQ: Bass, Layer Xfade"
		MIDI 24	"InEQ: Treb, Pan adj, EnvCtl: Rel"
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Decay Time+PreDelay
		MIDI 27	Delay Mix (sys)
		MIDI 28	Chorus Delay Time
185	Ethereal Dawning	MIDI 29	Chorus Depth adj
		MPress	Vibrato
		AttVel	AltCtl
		MWheel	BandPass Freq+Width sweep
		Data	Layer enable
		MIDI 20	BandPass Width - Layer 1
		MIDI 22	BandPass Freq + Width - Layer 2
		MIDI 23	BandPass Width - Layer 3
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
MIDI 26	Hall Decay Time		
MIDI 27	Flange Wet/Dry		
MIDI 28	Flange FB		
MIDI 29	"Toggle: Flange + CDR, InEQ: Bass"		
186	RAVReligion^Prey	MPress	BandPass Freq
		MWheel	"Vibrato, Para EQ adj"
		Data	Toggle: RAVReligion + Prey
		MIDI 22	EnvCtl: Att ^ Shapemod Pitch
		MIDI 23	"InEQ: Bass, Shape amt, EnvCtl: Rel ^ LoPass Freq, EnvCtl: Dec+Rel"
		MIDI 24	"InEQ: Treb, LoPass Freq, EnvCtl: Rel + Dec"
		MIDI 25	Toggle: (Aux) Hall + (fx1) Room cut
		MIDI 26	"Hall Decay Time, Room Time"
		MIDI 27	Phaser center Freq
		MIDI 28	Phaser FLFO Depth
MIDI 29	Toggle: Room + Phaser		
MPress	Vibrato		

Standard K2600 ROM Objects

Program Control Assignments

ID	Name		
187	Voyage	MWheel	"Vibrato, LoPass Freq"
		Data	Layer enable
		MIDI 22	"Pitch LFO Rate, LoPass Freq+Res, EnvCtl: Imp+Att+Rel"
		MIDI 23	EnvCtl: Dec
		MIDI 24	EnvCtl: Rel
		MIDI 25	(Aux) Hall Level
		MIDI 26	Hall Time+HFDamp
		MIDI 27	Chorus Mix
		MIDI 28	Chorus FB
		MIDI 29	"Chorus Rate, St Image L/R Delay"
		MPress	"Vibrato, LoPass Freq"
		MIDI 70	AltCtl
188	WispSingsr^Glass	MWheel	"Vibrato, LoPass Res"
		Data	Toggle: WispSingsr + Glass
		MIDI 22	"LoPass Freq+Res, HiPass Freq"
		MIDI 23	"LoPass Freq, HiPass Res+Freq, Layer Levels"
		MIDI 24	EnvCtl: Att+Rel
		MIDI 25	(Aux) Hall + (fx1) Hall Wet/Dry
		MIDI 26	Hall Times+HFDamp
		MIDI 27	Chorus Wet/Dry
		MIDI 28	Delay Wet/Dry (sys)
		MIDI 29	Toggle: Hall + CDR
		MPress	Vibrato
		189	Luscious
Data	"Panner LFO Rate, Layer Delay, Layer Xfade"		
MIDI 22	EnvCtl: Imp+Att		
MIDI 23	"InEQ: Bass, EnvCtl: Dec"		
MIDI 24	"InEQ: Treb, EnvCtl: Rel"		
MIDI 25	(Aux) Hall Time+PreDelay+HFDamp		
MIDI 26	Flange Mix		
MIDI 27	Flange Rate		
MIDI 28	Flange FB		
MIDI 29	Hall PreDelay adj		
MPress	Vibrato		
Tempo	LoPass Freq		
190	LightMist^Padify	MWheel	Vibrato
		Data	Toggle: LightMist + Padify
		MIDI 22	"Pitch adj, LoPass Freq"
		MIDI 23	InEQ: Bass
		MIDI 24	InEQ: Treb
		MIDI 25	(Aux) Hall Level
		MIDI 26	Chorus Delay Time
		MIDI 27	Chorus Delay Depth
		MIDI 28	Delay Mix (sys)
		MIDI 29	Hall Time+PreDelay adj
		MPress	Vibrato
		191	VortexRev^Launch
Data	Toggle: VortexRev + Launch		
MIDI 22	"HiPass Freqs+Width, EQ adj"		
MIDI 23	"InEQ: Bass, Layer Xfade"		
MIDI 24	"InEQ: Treb, EnvCtl: Att+Rel"		
MIDI 25	(Aux) Hall Time		
MIDI 26	Hall PreDelay		
MIDI 27	Chorus Depth+Delay		
MIDI 28	Delay Mix+FB		
MIDI 29	Hall HFDamp		
MPress	Vibrato		

ID	Name				
192	Hello^A No Way	MWheel	LoPass Freq		
		Data	Toggle: Hello + A No Way		
		MIDI 22	"LoPass Freq LFO, Pitch mod"		
		MIDI 23	InEQ: Bass		
		MIDI 24	InEQ: Treb		
		MIDI 25	(Aux) Hall Level+Time		
		MIDI 26	Hall build+PreDelay		
		MIDI 27	Chorus FB		
		MIDI 28	Chorus Delay		
		MIDI 29	Delay Mix		
		MPress	Pitch mod		
		193	Environments	MWheel	""hi bird"" LFO Rate, Panner adj"
Data	""lo bird"" LFO Rate"				
MIDI 22	"ParaEQ Freq, shaper amt"				
MIDI 23	"Pitch adj, LoPass Freq, BandPass Freq+Width"				
MIDI 24	"HiPass Freq, Pitch (sine)"				
MIDI 25	"Chorus Level, rvb Level, CDR Wet/Dry"				
MIDI 26	(fx2) Chorus Wet/Dry				
MIDI 27	Phaser Wet/Dry				
MIDI 28	CDR Wet/Dry				
MIDI 29	Chorus Rate				
MPress	InEQ: Bass				
MIDI 70	AltCtl				
194	Gremlin Groupies	MWheel	"Layer Pitch, LoPass Freq+Res, Wrap adj"		
		Data	"Layer Pitch, LoPass LFO adj"		
		MIDI 22	"Layer Pitch, Pitch (Sine) adj"		
		MIDI 23	Layer Pitch adj		
		MIDI 24	"Layer Pitch, Wrap adj"		
		MIDI 25	(Aux) Hall Level		
		MIDI 26	"Pitcher Wet/Dry, LsrDelay Time+Wet/Dry"		
		MIDI 27	"Pitcher wts pair, Lsr Spacing"		
		MIDI 28	"Pitcher wts odd, Lsr Contour"		
		MIDI 29	Toggle: Pitcher + LaserDelay		
		195	Lost In Space	MWheel	"LoPass Freq adj, Pitch adj"
				Data	HiPass Freq adj
MIDI 22	LoPass + HiPass Freq adj				
MIDI 23	"Layer Pitch, EnvCtl- atk"				
MIDI 24	EnvCtl- Rel				
MIDI 25	Delay Mix				
MIDI 26	Delay Time				
MIDI 27	Ch FB				
MIDI 28	Ch Depth				
MIDI 29	Toggle: (Aux) Plate I/O				
MPress					
196	Lunar Wind			MWheel	LoPass Freq+Res
		Data	Pitch adj		
		MIDI 22	"LoPass Res, Pan adj"		
		MIDI 23	Panner sweep		
		MIDI 25	(Aux) Room Level		
		MIDI 26	Pitcher Wet/Dry		
		MIDI 27	Flange Mix (sys)		
		MIDI 28	Pitcher Pitch		
		MIDI 29	Toggle: Pitcher I/O		
		MPress	"LoPass Freq, Pan LFO"		
		ChanS	EnvCtl: Rel		
		Breath	LoPass adj		

Monaural Piano Programs

Most of the piano programs are set to play in stereo, though **773 MonoStudioGrand**, as well as a number of programs on the accessory disk are designed for mono use. If the pianos are to be played through a mono sound system, the best results will come from these mono programs, not the stereo programs mixed to mono.

Stretch Tuning

Unless otherwise noted, piano programs are “stretch” tuned, like an acoustic piano. Since the higher harmonics of a stretched string tend to be sharper than those of the real harmonic series, stretch tuning ensures that the piano remains in tune with itself harmonically. Stretch tuning is sometimes referred to as “solo” or “beat” tuning.

Keymaps with **440** as part of their name—like **776 Mono Piano 440**—offer straight (non-stretch) tuning, where the fundamental of each note is tuned to A440. Programs that use these keymaps (for example **780 Ballad Piano**) will mix better with other acoustic and electronic instruments. This type of tuning, therefore, is sometimes known as “ensemble” tuning.

