THANK YOU FOR CHOOSING A MORLEY GEORGE LYNCH MINI DRAGON 2 WAH. YOU NOW OWN THE BEST PEDAL MADE!

Please take a few minutes to familiarize yourself with the features of your new pedal. We hope you enjoy using it as much as we enjoyed building it.

ABOUT OUR ELECTRO-OPTICAL CIRCUITRY:

An LED (Light Emitting Diode) shines on an LDR (Light Dependent Resistor). A shutter alters light between the two components controlling functions like Wah, volume and switching. Electro-Optical design ensures smooth pedal control without unwanted noise typical with potentiometer (pot) controlled pedals.

ABOUT THE CONNECTIONS:

9V (**Right side of Pedal**): To ensure noise free operation, ONLY Morley's 9VDC 300

milliamp regulated adapter should be used

先 IN (Right side of Pedal): Input jack. Plug instrument into this jack using 1/4" guitar cable.

生 OUT (Left side of Pedal): Connect amplifier to this jack using a 1/4" guitar cable.

USING AN AC ADAPTER:

All Morley pedals use Morley's 9VDC 300 milliamp regulated adapter. Center pin polarity is negative. Using a non-regulated adapter could cause a low frequency hum in your amplifier. Using an adapter with the wrong polarity may damage the pedal.

USING A BATTERY:

All Morley pedals are designed to use one 9V battery when not using an adapter. We suggest you use a good quality alkaline battery. To prolong battery life, unplug your cord completely from the input jack when not using the pedal. When the pedal is not used for extended periods, remove the battery from the pedal. Our "Quick Clip" Bettery door allows easy access to battery compartment.

ONE YEAR WARRANTY

All Morley® pedals are warranted for one year with copy of dated purchase receipt. To obtain warranty service, contact store where pedal was purchased or email contact@morleyebtech.com

MINI DRAGON 2 WAH FEATURES (MODEL MTG2):

- WOW Switch: Selects between standard Wah and WOW modes. LED lights when in WOW mode.
- LOUDNESS Knob: Adjust Wah output level in either Wah or WOW modes.
- WAH LOCK Switch: Electronically locks pedal into Wah mode. LED lights when in WAH LOCK mode.
- NOTCH Knob: When in WAH LOCK this adjusts the frequency of the Wah tone. Equivalent to moving the Wah Treadle.

MTG2 SPECIFICATIONS:

Power: 9V Battery or 9VDC 300mA regulated (center pin negative)

Indicator: WOW mode LED on, Wah mode LED off Indicator: WAH LOCK LED on, Bypass LED off

Dimensions: 6.75" L x 4.5" W x 2.75" H

Current Draw: 13 mA @ 9VDC

Weight: 2.1 lb./ 0.95 kg www.morleyproducts.com



Limited Edition Only 600 pcs Created Worldwide