

Roland

Expansion Kit

SR-GR1-01

for GUITAR SYNTHESIZER

GR-1

Owner's Manual

Thank you for purchasing the Roland Sound Library "Expansion Kit" (SR-GR1-01). The SR-GR1-01 is a Tone expansion kit specifically designed for increasing the number of sounds in the GR-1 Guitar Synthesizer.

A standard GR-1 contains 200 different Tones in its internal memory, but that can be expanded to 400 with the installation of this upgrade kit.

This kit also contains a Patch Card (PN-GR1-01) which includes 64 different Patches that use the Tones on the Expansion Board. In addition, the card contains many new SFX and ethnic percussion sounds.

Installing this Expansion Kit will greatly increase the potential of your GR-1.

* When installing, contact qualified service personnel.

26053891 '93-2-AE2-11K

Selecting a Patch

1. Insert the Patch Card into the Card Slot.
2. Press PATCH GROUP [UP] / [DOWN] to select Patch Group "3" or "4."
3. Select a Patch you like using the VALUE [INC] / [DEC] buttons or Bank Up / Down Pedals and Number Pedals.

EXPANDING THE DRUM SET

With the installation of the SR-GR1-01, it is possible to access a wide variety of additional sounds not found in the standard GR-1 configuration. For a detailed explanation about this, refer to the GR-1 manual (pages 9 - 15).

Selecting Songs

1. Insert the Patch Card into the Card Slot.
2. Press [EDIT SYSTEM].
3. Select [S-COMMON] using PARAMETER [PREV] / [NEXT].
4. Press [ENTER / YES].
5. Select [SONG INT] using PARAMETER [PREV] / [NEXT].
6. Change the display to [SONG CRD] using VALUE [INC] / [DEC].
7. To play a song on the card, press [START / STOP].

* For a detailed explanation, refer to the GR-1 manual.

Demo Song and Profile of Composer

FRET SALAD

Music by Paul Youngblood

Copyright (C)1993, Roland US


Paul Youngblood is a sound designer, author, composer, performer, and noted authority on electronic musical instruments. He has done sound design work for top artists such as George Michael, Lee Ritenour, KISS, and Larry Carlton. A graduate of the Berklee College of Music, Paul is the author of the Hal Leonard publication MIDI Guitar and Synthesis, an important reference book for guitar synthesists. Paul regularly conducts clinics for Roland, Guitar Institute of Technology, Dick Groves School of Music, and is a part-time instructor for the UCLA Extension Program.

Selecting a Tone

1. Select the desired Patch.
2. Press STRING MODE [CHANGE] as many times as necessary until only the 1st Tone sounds.
3. Press ORIGINAL TONE [1st].
4. Select the Tone you like using the VALUE [INC] / [DEC] buttons or the Bank Up / Down Pedals and Number Pedals.

TONE NUMBER DISPLAY

The GR-1 indicates Tone Numbers above 200 in a rather special way. To indicate a Tone Number between 200 and 299, only the lower half of the far-left digit will light. To indicate a number between 300 and 399, only the upper half of the digit will light.



200 — 299



300 — 399

TONE LIST

No.	Name	No.	Name	No.	Name	No.	Name
200*	60S EP 1	250	SOFT TPT	300*	ROCKLEAD	350	GTR PLUK
201	60S EP 2	251	SOLOHORN	301*	SWEEP LD	351	BRS PLUK
202*	SPACYPNO	252*	HORNZ	302*	GTR ORCH	352*	GLSMARBA
203	E PIANO3	253	BRETHSAX	303*	CRUNCH	353*	SEQ BLIP
204*	E PIANO4	254	BARI SAX	304	KLACK LD	354	ORCHHIT1
205*	TREMO EP	255*	B+TSAXES	305*	DIGI LOW	355*	ORCHHIT2
206*	CLAVSTAK	256*	TPT+SAX2	306	RIP LEAD	356	CHINACYM
207	PAINCLAV	257	BAG PIPE	307*	BRS LEAD	357	RIDEBELL
208*	DTUNCLAV	258	SHAKU	308	PULSE 1	358	TAMB
209	CLAV 3	259*	INDOPIPE	309	PULSE 2	359	HI BONGO
210	PIPEORG2	260	CELLO 2	310	SAW 1	360	LO BONGO
211*	JUNO ORG	261*	DYNCELLO	311	SAW 2	361	TIMBALES
212*	FULL ORG	262	PIZZ STR	312	SQUARE	362	AGOGO HI
213*	DUALPIPE	263	JP STR3	313	TRIANGLE	363	CABASA
214*	ROAD ORG	264*	BRSTRING	314	SPECTRUM	364	MARACAS
215	60S ORG1	265	CHOIR 1	315*	UTOPIA	365	PEDAL HH
216*	ROCKORG2	266*	AIRY VOX	316*	PULSATER	366	HARD SNR
217*	ACORDION	267	MALE VOX	317*	BIGSWEEP	367	MONDOKIK
218	STEELGT2	268*	DBLMALE	318*	SQUARSWP	368	POWERTOM
219	12ST GT2	269*	SPEC VOX	319*	BEEHIVE	369	AGOGO LO
220*	18STR GT	270*	DOO LEAD	320*	POLYSYN2	370	WOODBK
221*	DTUN GTR	271*	PERC VOX	321*	JP PAD2	371	CONGASET
222*	FUNKGTR2	272*	VOXTREE	322	VECTPAD1	372	CNG HI
223*	GTR PAD2	273*	VOX+STR	323*	VECTPAD2	373	CNG LO
224*	12GT PAD	274*	PIPE+VOX	324*	OCT PAD2	374	CNG MHI
225*	STRATUS	275*	BELLVOX1	325*	HYBDPAD1	375	CNG MLO
226*	BRITE GT	276*	DIGIVOX2	326	SWEPPAD2	376*	REVERSE
227*	SYNACORD	277*	VOCODER	327*	FULOUTPD	377	SYN DRUM
228	KOTO	278	TBN SECT	328*	METALPD2	378	TRIANGLE
229	SHAMISEN	279*	BRS SEC4	329*	PADTREE	379	TIMPANI
230	SUNTUR	280*	SFZ BRS	330*	FANTASY2	380*	DRUM KIT
231	P BASS	281*	BIG BRS	331*	EP+PAD	381	CONCRTBD
232*	8STR BS	282*	SYNBRS4	332*	SPRKL PAD	382	TAIKODRM
233	FRETNOT	283*	BRETHBRS	333*	CONVERGE	383*	APPLAUSE
234*	DTUNFLS2	284*	JP BRS	334*	ETERNITY	384*	BIRD
235*	ROCKBASS	285	SOFT BRS	335	GLOCKEN	385*	MACHINES
236*	ATK BASS	286*	SPIT BRS	336	SANZA	386*	SMASH
237	ROCKMUTE	287	FLUFFBRS	337*	AFRICAN	387*	EXPLOSON
238*	SAW BASS	288	GR700 1	338	TEMPLE	388	GUN SHOT
239*	WOW BASS	289	SYNCLEAD	339*	D CHIME	389	LASERGUN
240*	WET BASS	290*	SYNC PAN	340*	ALPHABEL	390	SCRATCH
241*	TEKNO BS	291	RESOLEAD	341*	BELL AAH	391	THUNDER
242	NASTY BS	292*	RESO LD2	342*	BELL STG	392	WIND
243*	RESO BS2	293*	SQRLEAD2	343	CRYSTAL	393*	AIR
244*	RASPBASS	294	DIGILEAD	344	DIGIBELL	394	WNDCHIME
245*	SYNCBASS	295*	BCKWARDS	345*	GLASWAVE	395*	DBLCHIME
246*	BS SOLO	296*	FUZZLEAD	346*	SARABABY	396*	PINKBOMB
247	THUDBASS	297*	5TH LEAD	347	BELLPLUK	397*	BUZZSAW
248	SING FLT	298*	SOFT LD	348	DIGIPLK2	398*	INSECT
249	BASSOON	299*	NEWAGELD	349	DYNOPLUK	399	GHOSTS

* The Original Tone marked with "*" use two voices per note.

* 「No.」に*マークの付いているオリジナル・トーンは1音につき2ボイス使用します。

PATCH LIST

Group /Bank	Number			
	1	2	3	4
31	FACELEAD	BRTH TNR	MONSTER	12STRGTR
32	FRET NOT	SINGFLUT	HUGEPIPE	LATINKIT
33	60S EPNO	DTUN CLV	TREMO EP	ACORDION
34	STEELGTR	12STRPAD	SHAMISEN	SANTUR
35	ROCKMUTE	P BASS	CRUNCHBS	ROCKSPLT
36	BRASLEAD	DIGI LD2	CRUNCH	LEAD No5
37	GR700 LD	SQRLEAD2	ANA LEAD	RESOLEAD
38	GTR ORCH	SYNSWEEP	POLYSYN2	BIGSWEEP
41	HUGER JP	STRVOX	DYNOCELO	PIZZ STR
42	CHOIR	CHURCH	ROCKORGN	ALPHASYN
43	NEWAGELD	BASOON	BAGPIPE	HORNZ
44	BARI SAX	TRUMPET2	BANDSEC2	SPITBRS
45	SPARKLE	BABY PAD	SNOWY	SARASPAD
46	VSWBELLS	PLUKPLUS	GLASSATR	FANTASY2
47	UTOPIA	HEAVEN2	RAZORPAD	CHAINSAW
48	FINALE	EXPLOSON	CASPER	BRAVO

Roland®

26053891

UPC 26053891



1898

Roland®